

## **GeoMat – User's Manual**

# **A Program for the Analysis of Soil Supported Mats and Structural Slabs**

by

Luis Vasquez  
Shin Tower Wang  
Daqing Xu

for

**ENSOFT, INC.**  
3003 W. Howard Lane  
Austin, Texas 78728  
United States of America

*(Release Date: Aug. 2022)*

## **COPYRIGHT**

Copyright 2014-2022 by ENSOFT, INC.

All rights reserved.

Printed in the United States of America. Except as permitted under the United States Copyright Act of 1976, no part of this publication may be reproduced, translated, or distributed without the prior written approval of ENSOFT, INC.

## **SOFTWARE LICENSE AGREEMENT & DISCLAIMER**

***IMPORTANT NOTICE:*** Please carefully read the terms of the license agreement and disclaimer at the end of this book. You signify acceptance with those terms by usage of the software.

# Table of Contents

Table of Contents.....	iii
<b>List of Tables.....</b>	<b>xii</b>
<b>CHAPTER 1. Introduction .....</b>	<b>1-1</b>
1.1 General Description.....	1-2
1.2 Method of Analyses.....	1-2
1.3 Program Features and Change Log.....	1-3
1.3.1 GeoMat 1.0 (2004) .....	1-3
1.3.2 GeoMat 2.0 (2014) .....	1-4
1.3.3 GeoMat 3.0 (2022) .....	1-4
1.4 Technical Support .....	1-5
1.4.1 Preferred Methods of Software Support .....	1-5
1.4.2 Upgrade Verification and Internet Site .....	1-5
1.4.3 Renewal of Program Maintenance .....	1-6
1.4.4 Changes of Support Policy.....	1-6
<b>CHAPTER 2. Installation and Getting Started.....</b>	<b>2-1</b>
2.1 Installation Procedures.....	2-2
2.1.1 Installation of Single-User Version .....	2-2
2.1.2 Introduction of Network Version .....	2-7
2.1.3 Backup of Original Software.....	2-8
2.1.4 Software Updates on the Internet .....	2-8
2.2 Getting Started .....	2-8
2.2.1 Starting the program.....	2-8
2.2.2 File Management .....	2-9
2.2.3 View Management of Program Window .....	2-10
2.2.4 Data Input for Program Operation.....	2-11
2.2.5 Computation Options.....	2-13
2.2.6 Manipulating the Slab Model.....	2-14
2.2.7 Results .....	2-15
2.2.8 Option Menu .....	2-16

2.2.9	Selection Menu .....	2-17
2.2.10	Window Menu .....	2-18
2.2.11	Help Menu .....	2-19
CHAPTER 3.	Data Input .....	3-1
3.1	File Menu .....	3-2
3.1.1	File – New .....	3-2
3.1.2	File – New from template .....	3-2
3.1.3	File – Open .....	3-7
3.1.4	File – Save .....	3-8
3.1.5	File – Save As .....	3-8
3.1.6	File – Exit .....	3-8
3.2	Input Data Menu .....	3-9
3.2.1	Numeric Data Entries and Sign Conventions.....	3-10
3.2.2	Input Data -Title .....	3-11
3.2.3	Input Data – Material Properties .....	3-11
3.2.4	Input Data – Node Coordinates.....	3-15
3.2.5	Input Data – Time Stepping.....	3-15
3.2.6	Input Data – Soil Stiffness .....	3-16
3.2.7	Input Data – Element Type.....	3-18
3.2.8	Input Data – Element Connectivity .....	3-18
3.2.9	Input Data – Integration Points.....	3-18
3.2.10	Input Data – Nodal Constrains.....	3-18
3.2.11	Input Data – Nodal Loads .....	3-19
3.2.12	Input Data – Nodal Stiffness .....	3-19
3.2.13	Input Data – Distributed Loads.....	3-20
3.2.14	Input Data – Distributed Stiffness .....	3-20
3.2.15	Input Data – Concentrated Loads.....	3-21
3.2.16	Input Data – Equivalent Concentrated Loads.....	3-21
3.2.17	Input Data – Concentrated Stiffness .....	3-22
3.2.18	Input Data – Edge Load.....	3-22
3.2.19	Input Data – Edge Stiffnesses .....	3-23
3.2.20	Input Data – Node Sets.....	3-24

3.2.21	Input Data - Element Set .....	3-25
3.2.22	Input Data – Edge Sets.....	3-26
3.2.23	Input Data – Section Cut.....	3-27
CHAPTER 4.	Finite Element Mesh Adjustment.....	4-1
4.1	Introduction.....	4-2
4.2	Mesh Refinement .....	4-2
4.3	Change of Element Type.....	4-5
4.4	Change of Integration Rule.....	4-6
CHAPTER 5.	Program Execution and Output Reviews .....	5-1
5.1	Introduction.....	5-2
5.2	Computation Menu .....	5-2
5.2.1	Computation- Run Analysis .....	5-2
5.2.2	Computation- View Input File .....	5-3
5.2.3	Computation- View Output File .....	5-3
5.2.4	Computation- View Message File.....	5-4
5.3	Results Menu .....	5-5
5.3.1	Results – Select Step .....	5-7
5.3.2	Results – Deformed Mesh .....	5-7
5.3.3	Results – Contour Plot.....	5-8
5.3.4	Results – Section Cut Plot.....	5-11
5.3.5	Results – Nodal Result.....	5-12
5.4	Speed Buttons in Graphics Mode .....	5-12
CHAPTER 6.	Examples .....	6-1
6.1	Introduction.....	6-2
6.2	Example 1: Cantilevered square plate simulated by single quadratic element .....	6-2
6.2.1	Problem Description.....	6-2
6.2.2	Modeling Instruction .....	6-2
6.2.3	Output Results Review .....	6-4
6.3	Example 2: Fixed square plate subject to concentrated force at center .....	6-5
6.3.1	Problem Description.....	6-5
6.3.2	Modeling Instruction.....	6-6
6.3.3	Output Results Review .....	6-8

6.4	Example 3: Square slab on soil - distributed stiffness method .....	6-9
6.4.1	Problem Description.....	6-9
6.4.2	Modeling Instruction.....	6-9
6.4.3	Output Results Review .....	6-10
6.5	Example 4: Square slab on soil - Mindlin method .....	6-11
6.5.1	Problem Description.....	6-11
6.5.2	Modeling Instruction.....	6-11
6.5.3	Output Results Review .....	6-13
6.6	Example 5: Slab on soil to support four columns (no rotation restraint).....	6-14
6.6.1	Problem Description.....	6-14
6.6.2	Modeling Instruction.....	6-14
6.6.3	Output Results Review .....	6-15
6.7	Example 6: Slab on soil to support four concentrated forces (restrained nodal rotation) .....	6-17
6.7.1	Problem Description.....	6-17
6.8	Example 7: Rectangular slab on soil subject to column loads.....	6-19
6.8.1	Problem Description.....	6-19
6.8.2	Modeling Instruction.....	6-19
6.8.3	Output Results Review .....	6-20
6.9	Example 8: Rectangular raft on soil to support columns and walls .....	6-23
6.9.1	Problem Description.....	6-23
6.9.2	Modeling Instruction.....	6-23
6.9.3	Output Results Review .....	6-24
6.10	Example 9: Wind turbine foundation supported by drilled shafts .....	6-26
6.10.1	Problem Description .....	6-26
6.10.2	Modeling Instruction .....	6-28
6.10.3	Output Results Review .....	6-34
6.11	Example 10: Square slab on soil - Vlasov method .....	6-37
6.11.1	Problem Description .....	6-37
6.11.2	Modeling Instruction .....	6-37
6.11.3	Output Results Review .....	6-39
6.12	Example 11: Circular wind turbine foundation – Vlasov method.....	6-42
6.12.1	Problem Description .....	6-42

---

6.12.2	Modeling Instruction .....	6-42
CHAPTER 7.	References .....	7-1
	License Agreement & Disclaimer .....	7-1

# List of Figures

Figure 2.1 Main installation screen for ENSOFT software (may change with time) .....	2-3
Figure 2.2 Installation Screen with License Agreement (may change with time) .....	2-4
Figure 2.3 Selection of Single-User License (may change with time) .....	2-5
Figure 2.4 Default Installation Directory for Example Files (may change with time) .....	2-5
Figure 2.5 Default Installation Directory for Program Files (may change with time) .....	2-6
Figure 2.6 File Extension Association for GeoMat Data Files (may change with time) .....	2-6
Figure 2.7 Default Shortcut Folder in Windows Start Menu (may change with time) .....	2-7
Figure 2.8 Default starting screen for GeoMat .....	2-9
Figure 2.9 Sample File Menu .....	2-10
Figure 2.10 View Menu .....	2-11
Figure 2.11 Sample Input Data Menu .....	2-13
Figure 2.12 Computations Menu .....	2-14
Figure 2.13 Sample Transform Menu .....	2-15
Figure 2.14 Sample Results Menu .....	2-16
Figure 2.15 Available items contained in the Options menu .....	2-17
Figure 2.16 Options contained in the Selection menu .....	2-18
Figure 2.17 Options contained in the Window menu .....	2-19
Figure 2.18 Options contained in the Help Menu .....	2-20
Figure 3.1 Window screen for the File menu .....	3-2
Figure 3.2 Options for various template .....	3-3
Figure 3.3 Input screen for the Circular option .....	3-3
Figure 3.4 Input screen for the Rectangular option – Equally Spaced option .....	3-4
Figure 3.5 Input screen for the Rectangular option – Generally Spaced option .....	3-4
Figure 3.6 Grid Y direction input screen for the Rectangular option – Generally Spaced option .....	3-5
Figure 3.7 Template for octagon wind turbine foundation .....	3-6
Figure 3.8 Template for circular wind turbine foundation .....	3-7
Figure 3.9 Window screen for the File – Open dialog .....	3-8
Figure 3.10 Message window advising that changes were not saved to disk .....	3-9
Figure 3.11 Options contained in the Input Data menu .....	3-10
Figure 3.12 Window screen for sample Data – Title .....	3-11
Figure 3.13 Window screen for material selection under Input Data Menu – Material Properties .....	3-12
Figure 3.14 Window screen for material data Under Material Properties .....	3-12
Figure 3.15 Window screen for material data Under Material Properties using uniform plate with orthotropic reinforcement .....	3-13
Figure 3.16 Window screen for material data Under Material Properties using orthotropic plate with enhanced stiffener .....	3-14
Figure 3.17 Window screen for material data Under Material Properties using orthotropic plate with one-way box section .....	3-14
Figure 3.18 Window screen for material data Under Material Properties using user-defined section .....	3-15

Figure 3.19 Window screen for Input Data Menu – Time Stepping .....	3-16
Figure 3.20 Window screen for Input Data Menu – Default option .....	3-17
Figure 3.21 Window screen for Input Data Menu – Vlasov approach.....	3-17
Figure 3.22 Window screen for Input Data Menu – Mindlin equation.....	3-18
Figure 3.23 Window screen for Input Data Menu – Nodal Constraints .....	3-19
Figure 3.24 Window screen for Input Data Menu – Nodal Loads.....	3-19
Figure 3.25 Window screen for Input Data Menu – Nodal Stiffness .....	3-20
Figure 3.26 Window screen for Input Data Menu – Distributed Loads .....	3-20
Figure 3.27 Window screen for Input Data Menu – Distributed Stiffness.....	3-21
Figure 3.28 Window screen for Input Data Menu – Concentrated Loads .....	3-21
Figure 3.29 Window screen for Input Data Menu – Equivalent Concentrated Loads .....	3-22
Figure 3.30 Window screen for Input Data Menu – Concentrated Stiffness.....	3-22
Figure 3.31 Window screen for Input Data Menu – Edge Load.....	3-23
Figure 3.32 Window screen for Input Data Menu – Edge Stiffnesses .....	3-24
Figure 3.33 Window screen for Input Data Menu – Node Sets .....	3-25
Figure 3.34 Window screen for selecting nodal points under Input Data Menu – Node Sets .....	3-25
Figure 3.35 Window screen for Input Data Menu – Element Sets .....	3-26
Figure 3.36 Window screen for selecting nodal points under Input Data Menu – Element Sets.....	3-26
Figure 3.37 Window screen for sample Input Data Menu – Edge Sets .....	3-27
Figure 3.38 Window screen for selecting edges for Input Data – Edge Sets .....	3-27
Figure 3.39 Window screen for sample Input Data Menu – Section Cut .....	3-28
Figure 3.40 Sample of output data from Edge Sets option .....	3-29
Figure 3.41 Window screen showing cutting sections by using Input Data Menu – Section Cut.....	3-29
Figure 4.1 Mesh adjustment options contained in the Edit menu .....	4-2
Figure 4.2 Mesh adjustment for conventional circular/rectangular plate .....	4-3
Figure 4.3 Information message before mesh adjustment is processed.....	4-3
Figure 4.4 Refined mesh in both y and z directions.....	4-4
Figure 4.5 Refine mesh for wind turbine foundation .....	4-4
Figure 4.6 Change element type from Edit menu.....	4-5
Figure 4.7 Information message before change of element type is processed.....	4-5
Figure 4.8 Mesh after change of element type from 8-node to 4-node .....	4-6
Figure 4.9 Change integration rule from Edit menu .....	4-7
Figure 5.1 Options contained in the Computation menu .....	5-2
Figure 5.2 Sample use of Microsoft Notepad for editing input text of Example Problem 1. ....	5-4
Figure 5.3 Sample use of Microsoft Notepad for view output text of Example Problem 1.....	5-5
Figure 5.4 Sample use of Microsoft Notepad for view message file of Example Problem 1.....	5-6
Figure 5.5 Command options contained in Result menu .....	5-6
Figure 5.6 Sample screen of the Select Step command option .....	5-7
Figure 5.7 Sample screen of the Deformed Mesh command option.....	5-7
Figure 5.8 Combined display of deformed and undeformed configuration.....	5-8
Figure 5.9 Sample screen of the Contour Plot command option .....	5-9
Figure 5.10 Line contour option for vertical displacement in Contour Plot .....	5-9

Figure 5.11 Shading contour option for vertical displacement in Contour Plot .....	5-10
Figure 5.12 Shading contour option for moment distribution in Contour Plot .....	5-10
Figure 5.13 Shading contour option for stress distribution in Contour Plot .....	5-11
Figure 5.14 X-Y plot for plate forces along one cut line .....	5-11
Figure 5.15 Nodal output .....	5-12
Figure 5.16 Speed Buttons for graphics manipulation .....	5-13
Figure 5.17 Slab model displayed using the YZ View (Top) speed button .....	5-13
Figure 5.18 Slab model displayed using the ZY View (Bottom) speed button .....	5-14
Figure 5.19 Slab model displayed using the XY View (Front) speed button .....	5-14
Figure 5.20 Slab model displayed using the XZ View (Side) speed button .....	5-15
Figure 5.21 Slab model displayed using the XYZ View (3D View) speed button .....	5-15
Figure 5.22 Sample screen of the Rotation Angles command option .....	5-16
Figure 6.1 Example 1 slab, shown with marked and labeled nodal points .....	6-3
Figure 6.2 Example 1 slab shown with nodal constrains and nodal loads .....	6-4
Figure 6.3 Review output file example1.sou for displacement results .....	6-5
Figure 6.4 Example 1 slab shown with nodal constrains and nodal loads .....	6-5
Figure 6.5 Quarter model of fixed edge slab with center load .....	6-6
Figure 6.6 Defining edge nodes (BOTTOM edge nodes highlighted) .....	6-8
Figure 6.7 Contour plot of displacement in X for slab in Example 2 .....	6-9
Figure 6.8 New Project from Template dialog screen for Example 3 .....	6-10
Figure 6.9 Slab of Example 3 shown with soil stiffness and center point load .....	6-11
Figure 6.10 Slab of Example 4 shown with center load and edge restrains .....	6-13
Figure 6.11 Deformed shape of slab of Example 4 shown with center load and edge restrains .....	6-14
Figure 6.12 Deformed shape of slab of Example 5 .....	6-16
Figure 6.13 Contour plot of moment distribution in the y direction of Example 5 .....	6-16
Figure 6.14 Nodal output for moment $M_y$ at node 39 in Example 5 .....	6-17
Figure 6.15 Apply node rotation constrains to simulate non-rotation at column foot in Example 6 .....	6-18
Figure 6.16 Contour plot of moment distribution in the y direction of Example 6 .....	6-18
Figure 6.17 Moment $M_y$ at node 39 in Example 6 .....	6-19
Figure 6.18 Location of columns on raft of Example 7 .....	6-20
Figure 6.19 Deformed shape of slab with column loads of Example 7 .....	6-21
Figure 6.20 Moment distribution of the slab in the y direction of Example 7 .....	6-22
Figure 6.21 Deflection of the slab along the cutting line of Example 7 .....	6-22
Figure 6.22 Location of walls and columns in Example 8 .....	6-23
Figure 6.23 Location of edge set for U-shape wall in Example 8 .....	6-24
Figure 6.24 Deformation of slab in Example 8 .....	6-25
Figure 6.25 Contour of bending moment $M_z$ .....	6-25
Figure 6.26 Contour of bending moment $M_y$ .....	6-26
Figure 6.27 Conceptual sketch of drilled-shaft foundation supporting a wind turbine .....	6-27
Figure 6.28 Dimension of pile cap and the embedded mounting plate with two rings of anchor bolts .....	6-28
Figure 6.29 New Project from Template dialog screen for Example 9 .....	6-29
Figure 6.30 Node Set screen for Example 9 .....	6-30

Figure 6.31 Definition of Node Sets P1 and P2 for Example 9.....	6-30
Figure 6.32 Definition of Node Sets P3 and P4 for Example 9.....	6-30
Figure 6.33 Definition of Node Sets P5 and P6 for Example 9.....	6-31
Figure 6.34 Definition of Node Sets P7 and P8 for Example 9.....	6-31
Figure 6.35 Node numbers on the screen for Example 9 .....	6-32
Figure 6.36 Nodal constraints dialog screen for Example 9.....	6-33
Figure 6.37 Equivalent concentrated loads screen for Example 9.....	6-34
Figure 6.38 Contour of deflection of Example 9 .....	6-35
Figure 6.39 Contour of bending moment ( $M_y$ ) of Example 9 .....	6-35
Figure 6.40 Contour of shear on XY plane of Example 9.....	6-36
Figure 6.41 Bending moment ( $M_z$ ) along a cutting line of Example 9.....	6-36
Figure 6.42 Configuration of slab resting on soil of example 10 .....	6-37
Figure 6.43 Input soil properties in Vlasov approach .....	6-38
Figure 6.44 Define concentrated load at slab center.....	6-39
Figure 6.45 View node output for one specific node.....	6-39
Figure 6.46 Distribution of moment $M_y$ along cut line 1 in example 10 .....	6-40
Figure 6.47 Distribution of shear force $Q_{xy}$ along cut line 1 in example 10.....	6-40
Figure 6.48 Output of $\gamma$ , $k$ and $2t$ in example 10.....	6-41
Figure 6.49 Influence of mesh size to shear stress in example 10.....	6-41
Figure 6.50 WTB foundation resting on soil of example 11.....	6-42
Figure 6.51 Template for circular wind turbine foundation in example 11.....	6-43
Figure 6.52 main window for material definition in example 11 .....	6-44
Figure 6.53 Define Young's modulus and Poisson ratio for each slab sets in example 11 .....	6-45
Figure 6.54 Define soil property using Vlasov approach in example 11.....	6-45
Figure 6.55 Check equivalent nodal loads in example 11.....	6-45
Figure 6.56 Apply nodal constraints to remove rigid body motion in example 11.....	6-46
Figure 6.57 Deflection along cut line 1 in example 11.....	6-47

---

## List of Tables

Table 2.1 Files created in GeoMat runs .....	2-8
Table 6-1: Parameters of slab and soil in example 10 .....	6-37
Table 6-2: Parameters of slab and soil in example 11 .....	6-42

# **CHAPTER 1.      Introduction**

## 1.1 General Description

The program is aimed at the solution under static loading of two classes of problems encountered in structural engineering: a soil-supported mat or a structural slab. The mat or structural slab is modeled with linear finite elements. The shape may be rectangular, round, or irregular and the thickness may vary.

For the soil-supported mat, soil is assumed to have a linear response, defined as the subgrade modulus, and is characterized by a set of springs which can vary in stiffness at points under the mat. The springs can reflect horizontal and vertical resistance. The solution follows the classical Winkler model. This method of modeling soil has been widely used in the analysis of flexible beams and mats on elastic materials. Since the Winkler model, often referred to as a “one-parameter model”, cannot represent a continuous medium well, the modified Vlasov model by Vallabhan and Das (1988) was also introduced in GeoMat for solving the soil-structure interaction in continuous medium. The modified Vlasov model accounts for the effect of the neglected shear strain energy in the soil and shear forces that come from surrounding soil by introducing an arbitrary parameter,  $\gamma$ , to characterize the distribution of the vertical displacement in an elastic foundation using an iterative procedure. The modified Vlasov model has improved the accuracy of the solution computed based on the Winkler soil model.

When a structural slab is analyzed, the supports can be assumed to exist at the edges, or along the interior of the slab, as for beams. The edges of the slab are assumed to be simply supported or subjected to a moment. The supports for the slab may be assumed to be unyielding or set of deflections may be specified. Iteration may be done externally to get agreement between deflection of the slab and that of the supporting beams. This program has the ability to compute deformation and stresses of isotropic or orthotropic plates based on the first order Mindlin thick plate theory. The orthotropic plates include uniform plates with orthotropic reinforcements, plate with orthotropic enhanced ribs, and plate with one way box section. The program also allows the user to define the orthotropic plates/slab with the user-specified properties.

*GeoMat* allows the user to specify loadings on the surface of the mat or slab as uniform, or distributed, or concentrated as from columns. Horizontal loads may be applied as well as vertical. The finite-element method employed by this program can take into account the variety of loadings as well as the properties of the material in a structure. With modern methods of characterizing material in the mat or slab and with the capability of desktop computers, solutions to finite-element arrays proceed rapidly and with a degree of accuracy in the control of the user.

The program does not set a limit on the number of finite-element meshes for modeling. Only the size of RAM in the user's computer will limit the available meshes. The element types include 4-node linear elements, 8-node quadratic elements, and 9-node Lagrangian elements. The soil is assumed to behave in the linear range, but the user may assign different values of subgrade stiffness at desired locations of the foundation.

## 1.2 Method of Analyses

The engineer must make several initial steps in performing the analysis and design of a soil-supported mat or a structural slab: 1. estimate the allowable bearing capacity of the mat or the resistance provided by the structural members supporting the slab; 2. estimate settlement and differential movement of the mat or slab; and 3. estimate the moments and shears for the structural design of the mat or slab. Assuming that a geotechnical engineer has provided information on the soil, leading to an estimate of the

bearing capacity of the mat, the experience of the structural engineer will allow for the sizing of the mat or slab for the initial analyses.

With regard to the soil-supported mat, the initial data provided by the geotechnical engineer may show a range of values because settlement and differential movement are difficult to estimate because the settlement is dependent on the stiffness of the soil and on the rigidity of the mat.

Loadings on a mat or a slab can vary widely in nature and magnitude. The finite-element method has been the best tool to take into account the variety of loadings as well as the properties of the material in a structure. With modern methods of characterizing material in the mat or slab and with the capability of desktop computers, solutions to finite-element arrays proceed rapidly and with a degree of accuracy in the control of the user.

For a given set of loadings, deformations and movements within the mat and slab can be computed, along with bending moment and shear stress at any point with the material. These results provide the engineer with information used for the design of the system. The method can be applied to a mat or slab that is circular, rectangular, or an irregular shape, leading to a powerful analytical tool interpreted comparably. Furthermore, in only a few instances have measurements been made, using the necessary instrumentation, that reveal the detailed manner in which the foundation interacts with the supporting soil.

For the mat on foundation, information is available in technical literature on subgrade modulus. Plainly, the reaction of soil against the base of a foundation is dependent on the deflection of the foundation; therefore, the value of the subgrade modulus is not constant. For many problems of a mat on foundation, however, a constant value of subgrade modulus will lead to acceptable solutions because deflections in most cases are relatively small. The ability to compute the settlement of the mat at all points will allow the engineer to use judgment about the value of modulus being used and adjustment in the value can be made where indicated. The ability to study the influence of the various parameters that entered in the problem gives the engineer powerful tools for analysis and design.

## **1.3 Program Features and Change Log**

### **1.3.1 GeoMat 1.0 (2004)**

The initial version was able to consider the soil-structure-interaction by using a generalized Finite-element thick-plate model, and then analyze the behavior of slab or mat supported by soil springs as subgrade. The first version of Program GeoMat has the following features that are designed to enhance the ability of the engineer to obtain usable results.

- The program employs well-established analytical solutions for soil-structure interaction under static loading.
- The program does not set a limit on the number of finite-element meshes for modeling. Only the size of RAM in the user's computer will limit the available meshes. The element types include 4-node linear elements, 8-node quadratic elements, and 9-node Lagrangian elements.
- The soil is assumed to behave in the linear range, but the user may assign different values of subgrade stiffness at desired locations of the foundation.
- The user may input various concentrated loads at nodal points, distributed loads at any element, and uniform loads for an entire mat or slab.

- The user may specify a mat or slab with any shape. The program has the capability to generate automatically finite meshes for mats or slabs with rectangular shapes or circular shapes.
- The program will display the layout of finite-element meshes with nodal numbers and element numbers.
- The program will generate contour graphics of slab deformation and stress distribution.

A Windows GUI (Graphic User Interface) was used for input screens and file operation. All variables have on-line text description or graphical symbols for definition. Also, all input data can be saved and retrieved from disk. Finally, graphical output of pressure distribution, deflection moment, and shear could be printed.

### 1.3.2 GeoMat 2.0 (2014)

The second version was developed in 2014 with several significant upgraded features and is fully compatible with the latest operation systems including Microsoft Windows 7 and 8.

- The program does not set a limit on the number of finite element meshes for modeling. Only the size of RAM in the user's computer will limit the available meshes. The element types include 4-node linear elements, 8-node quadratic elements, and 9-node Lagrangian elements.
- The program enhances the contour graphics of slab deformation and stress distribution.
- The program adds the function for “Section Cut” which is a useful tool to plot deflection, bending moment, or stress components along one or more straight cut lines.
- This version has the ability to compute deformation and stresses of space orthotropic plates. Three common types covered in this version are: uniform plates with orthotropic reinforcements, plate with orthotropic enhanced ribs, and plate with one way box section.
- This software also provides the option for inputting user-defined orthotropic properties.

### 1.3.3 GeoMat 3.0 (2022)

The third version was developed in 2021 and 2022 with several significant upgraded features and is fully compatible with the latest operation systems including Microsoft Windows 10 and 11.

- The program includes the modified Vlasov model by Vallabhan and Das (1988) for solving the soil-structure interaction in continuous medium. The modified Vlasov model has improved the accuracy of the solution computed based on the Winkler soil model.
- The program enhances the performance of 4-node linear elements in addition to the available choices on a high-order quadratic elements (8-node) and Lagrangian elements (9-node).
- The program adds a template to generate automatically finite meshes for wind-turbine gravity foundations using octagon or circular shapes with various concrete thickness.
- The program adds a practical example which is a useful reference for modeling the mat foundation supported by piles (pile-raft foundations).
- This version has the ability to assign the external loads from anchor bolts, which may be arranged in circular rings, directly onto the associated nodes as inputted concentrated loads.

## 1.4 Technical Support

Although computer program GeoMat was designed to be distinguished by its ease of use and by its accompanying User's Manual, some users may still have questions. The technical staff at ENSOFT strongly supports all registered users with questions related to the installation or use of GeoMat, according to the stipulations presented below. The software is provided with free maintenance service for the first year. After the first year the user is encouraged to purchase the yearly maintenance services. The yearly maintenance includes free download of the latest version/update and free technical support for installation and usage issues as described below.

### 1.4.1 Preferred Methods of Software Support

Software support is given, in order of preference, by the following methods:

- Electronic mail to: [support@ensoftinc.com](mailto:support@ensoftinc.com)
- Fax to: (512) 244-6067
- Telephone call to: (512) 244-6464, extension 2

Users are encouraged to utilize electronic means of support via email. In all technical support requests via email, please include the following information:

- full software version/release/update (obtained from the Help > About dialog),
- a description of the user's problem or concern,
- attach a copy of the input-data file that is associated with the issue/concern (files with name/extension of the type *filename.slb*), and
- name and telephone number of the contact person and of the licensed user (or name and office location of the licensed company site and/or serial number of the USB Key).

Although immediate answers are offered on most technical support requests, please allow up to two business days for a resolution in case of difficulties or schedule conflicts.

Technical help by means of direct calls to our local telephone number, (512) 244-6464, is available, but is limited to the business hours of 9 a.m. to 5 p.m. (US central time zone, UTC -6:00). The current policy of Ensoft is that all telephone calls for software support will be answered free of charge if the user has a valid maintenance contract.

### 1.4.2 Upgrade Verification and Internet Site

Starting from GeoMat v2022 the software provides options for the user to check the most recent maintenance release through an internet connection by selecting Help > Check for Updates. This command starts the default internet browser and will display the user's maintenance expiration date, the user's software release number and the most recent release number that is available for downloading.

If the user's version is not the latest version and the maintenance has not been expired, the user can download the latest version from our web server directly ([www.ensoftinc.com](http://www.ensoftinc.com)). Users may also consult our internet site for additional information on software updates, demos, and new applications; technical news; and company information.

### **1.4.3 Renewal of Program Maintenance**

The cost to renew program maintenance will depend on the length of time for which the program maintenance has been expired. There are small price increases with time after expiration. The pricing policy for renewing a program maintenance that has not expired can be found on the Ensoft website at [https://www.ensoftinc.com/order\\_form](https://www.ensoftinc.com/order_form)

### **1.4.4 Changes of Support Policy**

The software support policy and associated expenses are subject to change at ENSOFT's discretion and without specific mailed notices to the users. However, any change of rules will be verbally provided during telephone calls for software support.

## **CHAPTER 2.      Installation and Getting Started**

## 2.1 Installation Procedures

Program GeoMat is distributed with an associated USB key (hardware key or dongle). The hardware key consists of a device that is attached to an empty USB port (or USB hub) of the computer in use (or in the designated software server in the case of local network licenses). This method of software protection has been found to provide compatibility with existing operating systems, better stability than other alternatives, and allows users to obtain software updates or replacements via downloads from the internet.

Before installing, your computer should be equipped with the following:

- An open USB port
- At least 30MB of free space
- Windows 7,8,10,11

The file, contained in the distribution media, is a Windows-based program which will assist the user in installing all program modules into a user-selected directory with the proper settings used for the Windows environment. The user is assumed to have basic knowledge in running applications under MS Windows. The following steps are recommended for a successful installation.

### 2.1.1 Installation of Single-User Version

This version of GeoMat has been tested to be compatible with the following versions of the Microsoft Windows® operating systems: Win 11, 10, Windows 8.1, 8, 7, Vista, XP, 2000 in either 32 and 64-bit releases.

The following guidelines are recommended during the installation process of GeoMat for single-user licenses.

1. Plug the supplied USB Key into one of the available USB ports in your computer. The USB Key is plug-and-play compatible so the operating system will recognize the USB Key automatically and a small solid green light should appear at the end of the USB Key (a flickering green light or no light indicate problems with the standard windows driver or with the USB Key).
2. If the user installs from a distribution USB Memory Stick and the main installation program does not start automatically upon insertion of the Memory Stick then click on the Windows **Start Menu** button and select **Run**. On the command line, type *d:\setup.exe* or *e:\setup.exe*, where *d:* or *e:* represents the drive that contains the distribution Memory Stick. Click **OK** to execute the command and start the main installation program for ENSOFT's software. A screen similar to the one in Figure 2.1 should appear.

If the user installs from a downloaded file, then please run the downloaded file (double click) and go to instruction #4.

3. Click anywhere on the **GeoMat 2022** icon and then click on the **Install Standard** button to start the installation of GeoMat.
4. The user should read the license agreement shown in Figure 2.2. Users can review the License Agreement online in the following link:

<https://www.ensoftinc.com/doc/Ensoft%20License%20and%20Disclaimer.pdf>

The installer will place the same file (*Ensoft License and Disclaimer.pdf*) in the installation directory. Please click **Yes** if you agree and would like to proceed.

5. Select **Single-User License** in Figure 2.3 then click **Next**. For network installations please contact Ensoft support ([support@ensoftinc.com](mailto:support@ensoftinc.com)).
6. The user will be provided with an option to select a drive and directory for the installation of example files (see Figure 2.4). Default installation directory is the following:

*(Root Drive)\Ensoft\GeoMat2022-Examples*

7. The user will also be asked to select a drive and directory for the installation of GeoMat (see Figure 2.5). Default installation directory (varies according to the Windows release where it is installed) is one of the following:

*(Root Drive):\Program Files (x86)\Ensoft\GeoMat2022*

*(Root Drive):\Program Files\Ensoft\GeoMat2022*

If the desired directory does not exist, the installation program will automatically create a new directory in the chosen hard drive.



Figure 2.1 Main installation screen for ENSOFT software (may change with time)

8. During the installation the user will be asked to set the file extension association for opening GeoMat v2022 input data files (see Figure 2.6). If the user agrees (leaves the default check mark) then double clicking (or running) any input data file with extensions of the type *filename.slb* will start the installed GeoMat v2022 software.
9. The user will be prompted to confirm the shortcut directory name that will be created in the Windows Start Menu (See Figure 2.7). The default is *Start Menu/Programs/Ensoft/GeoMat2022*. Windows 11, 10 and 8 will automatically create an Ensoft tile with the same shortcuts.

After the installation is finished, it is usually not necessary to reboot Windows for the program to run. The user may run the program by selecting GeoMat v2022 from the standard links installed in the Microsoft Windows® Start Menu: Start Menu > All Programs > Ensoft > GeoMat2022




Figure 2.2 Installation Screen with License Agreement (may change with time)




Figure 2.3 Selection of Single-User License (may change with time)




Figure 2.4 Default Installation Directory for Example Files (may change with time)




Figure 2.5 Default Installation Directory for Program Files (may change with time)




Figure 2.6 File Extension Association for GeoMat Data Files (may change with time)




Figure 2.7 Default Shortcut Folder in Windows Start Menu (may change with time)

### 2.1.2 Introduction of Network Version

Special network licenses and USB hardware keys (network keys) are available for users that want to operate GeoMat on a Windows network. A network version is licensed for employees of one or more specific office sites that are within white listed subnets. Discounted rates apply for purchases of multiple network seats.

Network versions of GeoMat have special subroutines written for installations in “license manager” and for installations of “individual clients”. The “license manager” is known as the computer that will be carrying the network key provided by ENSOFT, INC. The license manager is not necessarily the same as the existing network server but rather just a computer carrying the network key and managing the license. Any computer in the existing Windows network may be designated license manager for GeoMat as long as the network key is attached to an available USB port (or through an USB hub) and the “server” version of the software (or of the Ensoft Utilities) is installed on its hard drive. Software “clients” may be all other computers of the network that have the program installed as client. Client computers do not need any hardware key attached to their local system. The program installed in “client computers” will be allowed to run as long as the computer designated as “license manager” is accessible on the network with the proper operating system and with its network key secured in place.

#### 2.1.2.1 Installation of Network Version

Installers of network licenses should refer to a separate booklet with installation instructions for the Network version of this product. The document can be downloaded from the Ensoft web site:

[https://www.ensoftinc.com/doc/Ensoft\\_Network\\_License\\_Installation\\_Booklet.pdf](https://www.ensoftinc.com/doc/Ensoft_Network_License_Installation_Booklet.pdf)

Alternatively, the document can be requested via email to [support@ensoftinc.com](mailto:support@ensoftinc.com)

### 2.1.2.2 Silent Installations on Client Computers

For installation of network licenses on local client computers there is an option for command-based installations that are completely silent (performed without other user input). Instructions for silent installations on client computers can be downloaded from the Ensoft web site using the following link:

<https://www.ensoftinc.com/doc/Silent%20Install%20on%20Client%20Computers.pdf>

Alternatively, the document can be requested via email to [support@ensoftinc.com](mailto:support@ensoftinc.com)

### 2.1.3 Backup of Original Software

The distributed software may be copied for backup purposes. The program may be installed in several computers at the same time. However, unless network licenses are purchased, the program will only operate in the computer that carries the appropriate USB Key.

### 2.1.4 Software Updates on the Internet

Occasionally, ENSOFT will produce software improvements and/or fixes and place the latest software programs on ENSOFT's internet site. Software users may download the latest program update from the PRODUCTS > Downloads link in the following site: <http://www.ensoftinc.com>

## 2.2 Getting Started

A first windows screen showing the menu choices, speed buttons, and operational controls of program GeoMat is presented in Figure 2.8. The following paragraphs provide a short description of the operational features of GeoMat and should quickly enable the user to get started with the program.

Several additional files are created in every new GeoMat run. A general description of these files is presented in Table 2.1. Every run of GeoMat thus generates four text files in the same drive and directory where the input-data file was saved or opened. Any of these files may be opened with standard text editors or word-processing programs.

File Name Extension	Usage Description	File Format	Example Files
*.slb	Input data file	GeoMat file	example1.slb
*.sin	Input data file	Text file	example1.sin
*.sou	Output data file	Text file	example1.sou
*.sms	Message file	Text file	example1.sms
*.sds	Timestep data file	Text file	example1.sds

**Table 2.1 Files created in GeoMat runs**

### 2.2.1 Starting the program

The program is started by double clicking the left mouse button anywhere in the GeoMat icon. A new window will appear on the screen, with the following top-menu choices: File, Edit, View, Input Data, Assign Data, Computation, Transform, Results, Options, Selection, Window, Help. As a standard

Windows feature, all underlined letters of top menu operations indicate that choices may also be accessed by keyboard combinations of ALT + [letter] (where [letter] represents the desired underlined letter).




Figure 2.8 Default starting screen for GeoMat

A list of recently opened files is displayed in between **Save As...** and **Exit**.

### 2.2.2 File Management

The File menu contains several commands for file management and to create new models. A sample is shown in Figure 2.9. Brief descriptions for each entry are as follows:

- New** ..... to create a new data file.
- New from Template** ... to create a new mesh data file with the template.
- Open\*** ..... to open an existing data file.
- Close...** ..... to close an existing data file.
- Save** ..... to save input data under the current file name.
- Save As...** ..... to save input data under a different file name.
- Print** ..... to print the current graphics.
- Print Preview...** ..... to view the graphic layout before sending to the printer.
- Print Setup** ..... to setup printer configuration.
- Page Setup** ..... to setup page border and configuration.
- Save As Bitmap** ..... to save graphics using Bitmap format.
- Exit\*\*** ..... to exit Program GeoMat.

\* **Open....**: If a partially completed GeoMat input file, or an invalid data file is opened, an information window reporting that an “invalid or incomplete” file is being opened. Clicking OK dismisses the message, and the previously saved data should be available. If a complete input file is loaded, an information window reporting that “Data File: (name of file), has been read by GeoMat” should appear, and the user should click OK.

\*\* **Exit**: If the input file was modified but unsaved, a prompt will appear asking if the user would like to save changes.




Figure 2.9 Sample File Menu

### 2.2.3 View Management of Program Window

The **View** menu contains several toolbar options, as shown in Figure 2.10. By default, these options are turned on when the program is launched. The choices are listed below, along with a general description of their use.

**File Toolbar** ..... this option displays the toolbar associated with the options contained in the **F**ile and **H**elp menus.

<b><u>V</u>iew Toolbar</b> .....	this option displays the toolbar associated with the options contained in the Transform menu.
<b><u>S</u>elect Toolbar</b> .....	this option displays the toolbar associated with the options contained in the Selection menu.
<b><u>A</u>ctions Toolbar</b> .....	this option displays the toolbar associated with the options contained in the Input Data menu.
<b><u>S</u>tatus Bar</b> .....	this option displays the status bar at the bottom of the screen.




Figure 2.10 View Menu

## 2.2.4 Data Input for Program Operation

The Input Data menu is provided for the control of program variables and preferences. The listing of menu options is shown in Figure 2.11 and the different submenu choices are briefly described below. The user may select any of the options without concern for the sequential order.

<b><u>T</u>itle</b> .....	this option allows the user to title the current evaluation. It is displayed in the Input File and Output File.
<b><u>M</u>aterial Properties</b> ..	as a default, the program considers the cross-section of the slab to be uniform. Young's modulus, Poisson's ratio, and slab thickness may be modified as needed. This version has the ability to compute deformation and stresses of space orthotropic plates. Four types are covered in this version: uniform plates with orthotropic reinforcements, plate with orthotropic enhanced ribs, plate with one way box section and general orthotropic plate.
<b><u>N</u>ode Coordinates</b> ....	the user should input in this box the coordinates of the mesh to be drawn on the slab. This action is already performed for the user if the problem was designed using the New from template... option in the <u>F</u> ile menu.
<b><u>T</u>ime Stepping</b> .....	the user should input in this box the coordinates of the mesh to be drawn on the slab.
<b><u>S</u>oil <u>S</u>tiffness</b> .....	this option allows the user to solve soil-slab interaction using Mindlin's Equation or Vlasov approach.

<b>Element Type</b> .....	three element types are available for use in the analysis: Linear 4-noded, Quadratic 8-noded, and Lagrangian 9-noded.
<b>Element Connectivity</b> ..	this window allows the user to specify the connecting edges of the elements. This action is already performed for the user if the problem was designed using the New from template... option in the File menu.
<b>Integration Points</b> .....	this option allows the user to select the number of integration points to be used in the analysis: 1x1, 2x2, or 3x3.
<b>Nodal Constraints</b> .....	this box allows the user to apply constraints at nodal points.
<b>Nodal Loads</b> .....	this option allows the user to apply loads at nodal points.
<b>Nodal Stiffness</b> .....	this option allows the user to apply stiffnesses at nodal points.
<b>Distributed Loads</b> ....	this option allows the user to select the element location and intensity of distributed loads.
<b>Distributed Stiffness</b> ..	this option allows the user to select the element location and intensity of distributed stiffnesses.
<b>Concentrated Loads</b> ..	this option allows the user to place a concentrated load at any location on the slab.
<b>Equivalent Concentrated Loads</b> ..	this option allows the user to place concentrated loads from anchor bolts of the mounting plate to the top of the foundation. The program will calculate the location of each anchor bolts arranged in a circular pattern and the distributed load on each anchor bolt based on the user-specified data.
<b>Concentrated Stiffness</b> ..	this option allows the user to place a concentrated stiffness at any location on the slab.
<b>Edge Loads</b> .....	this option allows the user to place a load along an edge.
<b>Edge Stiffness</b> .....	this option allows the user to place a stiffness along an edge.
<b>Node Sets</b> .....	this option allows the user to create node sets in order to facilitate the ease of defining nodal loads, stiffnesses, and constraints.
<b>Element Sets</b> .....	this option allows the user to create node sets in order to facilitate the ease of defining distributed loads, distributed stiffnesses, and material properties.
<b>Edge Sets</b> .....	this option allows the user to create node sets in order to facilitate the ease of defining edge loads and stiffness
<b>Section Cut</b> .....	This option allows users to define cut lines for XY curve plot.




Figure 2.11 Sample Input Data Menu

### 2.2.5 Computation Options

The **Computations** menu is provided to run the analytical computations after all data are entered and saved. After the computation is executed successfully, this menu also provides options for the reviews of plain-text input data, notes produced during computation, and output data. Submenu choices, shown in Figure 2.12, are briefly described below.

**Run Analysis** ..... this option is chosen to run the analytical computations. This option should be selected after all data have been entered and saved.

**View Input File** ..... this option calls Microsoft Notepad to observe and/or edit the analytical input data in plain-text format. The option becomes available after the input data has been saved to disk, or when opening an existing input-data file.

**View Output File** ..... this option calls Microsoft Notepad to observe, format, and/or print the analytical-output data. The option becomes available only after a successful run has been made. Certain output files may be too large for the Microsoft Notepad editor, so other text editors would have to be used (Microsoft WordPad should be able to open most text files).

**View Message File** .... this option calls Microsoft Notepad to observe the processor run notes which may include error messages.




Figure 2.12 Computations Menu

## 2.2.6 Manipulating the Slab Model

The Transform menu is used to manipulate and transform the slab model displayed in the program window. The user may also access these operations via the View Toolbar shortcuts. Submenu choices, shown in Figure 2.13, are briefly described below.

- Panning** ..... this function allows the slab model to be moved in the window.
- Rotate** ..... this function allows the slab model to be rotated around the origin.
- Zoom In/Out** ..... this function zooms in and out on the slab model.
- Restart** ..... this function resets the view to the original YZ plane view.
- YZ View (Top)** ..... this orients the slab in the YZ plane, looking at the top of the slab.
- YZ View (Bottom)** ... this orients the slab in the YZ plane, looking at the bottom of the slab.
- XY View (Front)** ..... this orients the slab in the XY plane, looking at the front of the slab
- XZ View (Side)** ..... this orients the slab in the XZ plane, looking at the top of the slab.
- XYZ View (3Dview)** .. this orients the slab in an orthographic 3D view.
- Rotation Angles** ..... this option allows the user to specify the desired rotation angle.




Figure 2.13 Sample Transform Menu

## 2.2.7 Results

The **Results** menu provides additional options for viewing the slab after an analysis has been completed. The submenu options, shown in Figure 2.14, are described below.

**Select Step** ..... this option allows the user to choose the number of steps used in the solution.

**Deformed Mesh** .... this option displays the deformed shape of the slab, based on the user's specified shape deformation factor. The undeformed shape may also be displayed alongside the deformed shape.

**Contour Plot** ..... this option creates a contour plot of various output information, such as deflection, rotation, shear, moment, and stress.

**Section Cut Plot** ..... this option creates xy plots of various output information along the user-selected cutting lines, such as deflection, rotation, moment, and stress.

**Node Results** ..... this option displays deformation, plate forces, reactions, and plate stresses of one specific node.




Figure 2.14 Sample Results Menu

### 2.2.8 Option Menu

The Options menu provides various options for displaying data about the slab on-screen. Submenu options, shown in Figure 2.15, are briefly described below.

- Mark Nodes** ..... this option marks the nodal points.
- Node Numbers** ..... this option displays the node numbers.
- Element Numbers** ... this option displays the element number.
- Boundary Only** ..... this option shows the slab and its edge boundary.
- Local Axes** ..... this option displays the axes associated with the slab.
- Global Axes** ..... this option displays the global axes of the workspace.
- Solid Face** ..... this option shows the elements as solid units.
- Show Thickness** ..... this option displays the thickness of the slab.
- Nodal Constraint** ..... this option displays the location of the user input nodal constraints
- Nodal Loads** ..... this option displays the location of the user input nodal loads.
- Nodal Stiffness** ..... this option displays the location of the user input nodal stiffnesses.
- Concentrated Loads** ..... this option displays the location of the user input concentrated loads.
- Concentrated Stiffness** ..... this option displays the location of the user input concentrated stiffnesses.
- Concentrated Total Stiffness** ..... this option displays the nodal, concentrated, and distributed stiffnesses.
- Distributed Loads** ..... this option displays the user input distributed loads.
- Distributed Stiffness** ..... this option displays the user input distributed stiffness.
- Edge Loads** ..... this option displays the user input edge loads.
- Edge Stiffness** ..... this option displays the user input edge stiffnesses.
- Font and Color** ..... this option lets users control fonts and colors used for node/element number.




Figure 2.15 Available items contained in the Options menu

### 2.2.9 Selection Menu

The Selection menu provides options for selecting different members of the slab. Submenu options, shown in Figure 2.16, are briefly described below.

**Select Node** ..... this option allows the user to select a node using the mouse button.

**Selection Element** ... this option allows the user to select an element using the mouse button.

**Select Edge** ..... this option allows the user to select an edge using the mouse button.




Figure 2.16 Options contained in the Selection menu

### 2.2.10 Window Menu

The Window menu provides the user with various ways to view the active documents. Submenu options, shown in Figure 2.17, are briefly described below. The open windows are listed at the bottom of the menu, after the divide line.

- New Window** ..... this option launches a copy of the current open window.
- Cascade** ..... this option stacks the open windows on top of one another.
- Tile Horizontal** ..... this option tiles the open windows horizontally.
- Tile Vertical** ..... this option tiles the open windows vertically.
- Arrange Icons** ..... this arranges the minimized windows




Figure 2.17 Options contained in the Window menu

### 2.2.11 Help Menu

The Help menu provides an online help reference on topics such as: using the program, entering data, information about variables used in the program, and methods of analyses. The Help menu may be accessed at any time while in GeoMat. Submenu options, shown in Figure 2.18, are briefly described below.

- Help Topics .....** the main reference files for help are accessed through this submenu option. Clicking on this option provides a screen with reference help for the following topics: File Menu, Edit Menu, View Menu, Input Data Menu, Computations Menu, Transform Menu, Results Menu, Options Menu, Selection Menu, Window Menu, and Help Menu. Under each topic are additional subtitles that corresponds to data-entry headings. If the user selects one of those, a help screen on the topic is displayed.
- User's Manual .....** this option is used to access a digital copy of the user's manual
- Technical Manual ....** this option is used to access a digital copy of the technical manual
- About .....** this displays a screen describing the program version, date, and methods for accessing technical support.




Figure 2.18 Options contained in the Help Menu

## **CHAPTER 3.      Data Input**

## 3.1 File Menu

This menu, shown in Figure 3.1, contains options related to the management of input data files and to exit the program. Input data files created for *GeoMat* are provided with a standard file-name extension in the form of \*.slb (where \* represents any allowable file name). All input-data files are standard text files and may be edited with any text editor or word-processing program.




Figure 3.1 Window screen for the File menu

### 3.1.1 File – New

Once the program is started, default values are used for certain operating parameters and a blank, input data file is created. Selecting **New** under the **File** menu resets all *GeoMat* variables to either default or blank values, as appropriate. This option should be selected when a new data file is desired to be created from a blank form. This menu option may also be accessed with the Ctrl+N keyboard combination

### 3.1.2 File – New from template

To assist the user in creating an input file, the **New from template** option may be selected. *GeoMat* provides three templates: conventional rectangular or circular plate, octagonal wind turbine foundation, or circular wind turbine foundation (Figure 3.2). Later two options are specifically used for soil-slab interaction of wind turbine foundations by means of Vlasov or Mindlin approach.




Figure 3.2 Options for various template

The first option is used for a conventional circular or a rectangular plate (Figure 3.3). A new template dialog box prompts the user for the geometric and computational properties of the slab. The shape, number of nodes for computation, dimensions, and number of grid divisions may be easily entered with this interface. This automatically fills the Node Coordinate, Element Type, and Element Connectivity data in the **Input Data** menu.

There are three types of shapes to choose from: Circular, Rectangular - Equally Spaced, and Rectangular - General Spacing. With each option, the bottom portion of the window reflects the needed input to draw the slab model. Examples of each screen associated with these choices are shown in Figure 3.3 to Figure 3.5. The Rectangular General Spacing allows users to input the grid locations, an example is shown in Figure 3.6. The user may also select the element type to be used in the analysis. Three types are available: Linear 4 noded, Quadratic 8 noded, and Quadratic 9 noded.




Figure 3.3 Input screen for the Circular option

The dialog box 'New Project from Template' has a close button (X) in the top right corner. It contains two main sections: 'Shape' and 'Element Type'. In the 'Shape' section, 'Rectangular - Equally Spaced' is selected with a radio button. In the 'Element Type' section, 'Quadratic 8 noded' is selected with a radio button. Below these sections, the 'Rectangular - Equally Spaced' configuration is shown. It includes input fields for 'Y-direction' (Length: 1, Number of divisions: 5) and 'Z-direction' (Width: 1, Number of divisions: 5). A diagram of a rectangular mesh is shown with 'Length' and 'Width' labels. A small 3D cube icon is in the bottom right corner. 'OK' and 'Cancel' buttons are on the right side.

Figure 3.4 Input screen for the Rectangular option – Equally Spaced option

The dialog box 'New Project from Template' has a close button (X) in the top right corner. It contains two main sections: 'Shape' and 'Element Type'. In the 'Shape' section, 'Rectangular - General Spacing' is selected with a radio button. In the 'Element Type' section, 'Quadratic 8 noded' is selected with a radio button. Below these sections, the 'Rectangular - General Spacing' configuration is shown. It includes input fields for 'Grid Y-direction' (Length: 0, Number of divisions: 0) and 'Grid Z-direction' (Width: 0, Number of divisions: 0). A diagram of a rectangular mesh is shown with 'Length' and 'Width' labels. A small 3D cube icon is in the bottom right corner. 'OK' and 'Cancel' buttons are on the right side.

Figure 3.5 Input screen for the Rectangular option – Generally Spaced option

	Number Divisions	Span Length	Total Length
1	1	5	5
2	2	3	8
3	3	4	12
4	4	5	12


OK  
Cancel  
Add Span  
Insert Span  
Delete Span  
Number of Spans  
4

**Figure 3.6 Grid Y direction input screen for the Rectangular option – Generally Spaced option**

If option 2 in Figure 3.2 is selected, a new template for octagon wind turbine foundation(WTB) is shown as in Figure 3.7.  $L_1$ ,  $L_2$  are plane dimensions for this octagon WTB.  $D$  is the diameter for the circular pedestal.  $D_1 \sim D_3$  are step sizes in the thickness direction. In this template, loads  $P$ ,  $V$  and  $M$  are optional.  $P$  is the vertical thrust force from tower weight, instrument weight or vertical component of wind loads.  $V$  is the shear force applied to the top of the foundation. Note that if the shear force  $V$  is non-zero, appropriate nodal constraints should be defined to avoid rigid body motion of the foundation. Non-zero loads  $P$ ,  $V$  and  $M$  will be discretized to equivalent nodal loads by GeoMat automatically. The default finite element is set to quadratic eight-noded element with 2x2 integration rule.

Element refinement is determined by typical element size. Majority of elements will be generated in the square shape and each edge will follow this size approximately. The default element size is estimated by GeoMat. Users can override it to generate a coarser mesh or a finer mesh by inputting a new size. Angle  $\alpha$  is the angle between load plane of  $V$ ,  $M$  and horizontal y axis. Positive angle is in the clockwise direction. As an example, entering 90 will define a wind load in the downward direction.

Template of Octagon Shape



Plane Dimension

L1 = 21.0

L2 = 17.0

D = 14.0

Angle(deg) = 0

Section Dimension

D1 = 1.5

D2 = 5.0

D3 = 3.5

Load

P = 600.0

V = 0.0

M = 50000.0

Finite Element Option

☐ Linear 4 noded

☒ Quadratic 8 noded

☐ Quadratic 9 noded

Typical FE Size 0.88

Integration Rule

☐ 1x1

☒ 2X2

☐ 3X3

OK Cancel

**Figure 3.7 Template for octagon wind turbine foundation**

The third option for the new template is also a wind turbine foundation in circular shape (Figure 3.8).  $R_1$  is the radius of the pedestal.  $R_2$  is the radius of the second circle.  $R_3$  is the radius at the foundation bottom. Other parameters have the same meanings as the octagon wind turbine foundation.

Template of Octagon Shape

Plane Dimension

R1 = 3.5

R2 = 5.0

R3 = 14.0

Angle(deg) = 0

Section Dimension

D1 = 1.5

D2 = 5.0

D3 = 3.5

Load

P = 600.0

V = 0.0

M = 50000.0

Finite Element Option

☐ Linear 4 noded

☒ Quadratic 8 noded

☐ Quadratic 9 noded

Typical FE Size 1.10

Integration Rule

☐ 1x1

☒ 2x2

☐ 3x3

OK Cancel

Figure 3.8 Template for circular wind turbine foundation

### 3.1.3 File – Open

This option is used to open a file that has been previously prepared and saved to disk. The **File - >Open** window dialog, shown in Figure 3.9, is used to search for an existing input-data file. By default, the file is initially searched in the directory where *GeoMat* was installed. Standard, windows-navigation procedures may be used to locate the name and directory of the desired project file. This menu option may be accessed with the Ctrl+O keyboard combination.

Every analytical run of *GeoMat* produces several additional files, as described in **Error! Reference source not found..** The name of the input-data file indicates the names of all related files produced by a successful execution (output, graphics, and processor-text files). All the additional program files will be created in the same directory as the input file. Input-data files that are partially completed may be saved and later opened for completion, run, and view of results.

Opening partially completed, input files or invalid data files may produce an information window reporting that an “invalid or incomplete” file is being opened. The user should click the OK button and all partial-input data that was previously prepared should become available.




Figure 3.9 Window screen for the File – Open dialog

### 3.1.4 File – Save

This option is used to save input data under the current file name. With this method of storing data to disk, any input data that was previously saved with the same file name is replaced with the current parameters. Input-data files should be saved every time before proceeding with runs for analytical computation. This menu option may also be accessed with the Ctrl+S keyboard combination.

### 3.1.5 File – Save As

This option allows the user to save any opened or new input data file under a different file name or different directory. Any input data file saved under an existing file name will replace the contents of the existing file.

### 3.1.6 File – Exit

This is selected to exit *GeoMat*. Any input-data file that was modified and not yet saved to disk will produce a confirmation window before exiting the program (see Figure 3.10).





Figure 3.10 Message window advising that changes were not saved to disk

## 3.2 Input Data Menu

The input of specific parameters for an application is controlled under options contained within this menu, shown in Figure 3.11. It is recommended that the user chooses each submenu and enter parameters in a consecutive manner starting from the top option.

Selecting or clicking any of the submenu choices contained in the Data menu produces various types of windows. As a reminder of standard commands of Microsoft Windows, open windows may be closed by all or some of the following methods:

- clicking the **OK** button (if available), or
- clicking the  box on the upper-right corner of the window, or
- double-clicking the *GeoMat* icon on the upper-left corner of the window, or
- using the Ctrl + o keyboard combination, or
- clicking once on the *GeoMat* icon on the upper-left corner of the window and then choosing Close.

Open windows may optionally be left open on the screen. The selection of other menu options will then produce new windows on top of those that were left open.

Many sub-windows of the **Data** menu will show an **Add Row**, **Insert Row** and/or **Delete Row** buttons. The **Add Row** button always adds new rows at the end after all existing rows. The **Insert Row** button always inserts a new row right after an existing row highlighted by the mouse. Clicking on the **Delete Row** button deletes the row where the cursor is located.

### 3.2.1 Numeric Data Entries and Sign Conventions

Cells that require numeric data only accept simple numeric entries. Entering a mathematical expression works similarly to normal numeric data. If a non-valid number is inputted, the program will display an error message.

The user is reminded to keep consistent units since units are not explicitly defined in the program. The sign conventions in this program are based on the right-hand rule, which use X direction for the load or displacement perpendicular to the plate and the plate planar dimension is defined in Y and Z directions.

Scientific notation (i.e. 1.65e8 or 1.65e-8) may be used to input very large or very small numbers. After an expression is calculated, very large or very small numbers will be displayed using scientific notation.




Figure 3.11 Options contained in the Input Data menu

### 3.2.2 Input Data -Title

This option activates the window shown in Figure 3.12, where the user can enter a line of text containing a general description for the application problem. Any combination of characters may be entered in the text box in order to describe a particular application. The user input will be restrained automatically once the maximum length of text is reached. This is done to prevent the user from going beyond the maximum permissible length of characters allowed for the title line.




Figure 3.12 Window screen for sample Data – Title

### 3.2.3 Input Data – Material Properties

This menu option launches the window shown in Figure 3.13, where the user can specify the type of materials. The current version of *GeoMat* allows the user to select Isotropic plate/slab and Orthotropic plate/slab with various configuration. The properties may be varied across different sections by using the Add Material function. The program will ask the user to select proper representation from the following five different categories: Isotropic, Orthotropic Reinforcement, Orthotropic Enhances Stiffener, Orthotropic One Way Box Section, and User Defined Property.

#### Isotropic Properties

Enter the Element Number/Set and after the material selection click the **Define** button, the screen for material properties will be shown for data entry (Figure 3.14), including the location of the material properties of the slab. The input requested is the Young's Modulus, Poisson's Ratio, and Slab Thickness. If the **New from template** option is used, the material properties are set to the default values of ALL for the Element Sets, 3000 for Young's Modulus, 0.3 for Poisson's Ratio, and 1 for Slab Thickness.




Figure 3.13 Window screen for material selection under Input Data Menu – Material Properties




Figure 3.14 Window screen for material data Under Material Properties

### Orthotropic Properties

This version can compute deformation and stresses of space orthotropic plates. Three types of orthotropic plates/slabs available in this version are: uniform plates with orthotropic reinforcements, plate with orthotropic enhanced ribs, and plate with one way box section. This version also provides the option for inputting user-defined orthotropic properties.

Type 1: Uniform plate with orthotropic reinforcement

The input interface is shown in Figure 3.15.  $A_{s1}$  and  $A_{s2}$  are areas of reinforcement above or below the plate neutral axis.  $X_1$  and  $x_2$  are distances from the center of reinforcement to the neutral axis.

Type 2: Plates with orthotropic enhanced stiffener

The input interface is shown in Figure 3.16. The dimension and location of each component on the orthotropic plate are sketched and shown in the input screen for the user to follow.

#### Type 3: Plates with one-way box section

The input interface is shown in Figure 3.17. The dimension and location of each component on the orthotropic plate are sketched and shown in the input screen for the user to follow, where  $t_1$ =thickness of top plate,  $t_2$ =thickness of vertical plates,  $t_3$ =thickness of bottom plates.

#### Type 4: User defined orthotropic plates

This option allows the user to define orthotropic plates. There are six input parameters that are needed for defining the orthotropic properties as shown in Figure 3.18. The flexural and shear rigidities are defined in the technical manual. (Note the x, y and z coordinate axes are defined differently than those used in user input GUI.)




Figure 3.15 Window screen for material data Under Material Properties using uniform plate with orthotropic reinforcement




Figure 3.16 Window screen for material data Under Material Properties using orthotropic plate with enhanced stiffener




Figure 3.17 Window screen for material data Under Material Properties using orthotropic plate with one-way box section

User Defined Orthotropic Property

Element Set: ALL

Young's Modulus of Concrete: 2000

Poisson's Ratio: 0.3

Thickness: 1

Flexural Rigidity

Dyy = 0

Dzz = 0

Dv = 0

Dyz = 0

Shear Rigidity

Dsy = 0

Dsz = 0

OK Cancel

Figure 3.18 Window screen for material data Under Material Properties using user-defined section

### 3.2.4 Input Data – Node Coordinates

This submenu allows the user to manually input the locations of each nodal point. If the **New from template** option is used, the coordinates are automatically determined and entered here for the user. For a mat that is neither rectangular nor circular, the user may enter the node coordinates one by one. The user may also modify the automatically generated node coordinates by adding new node coordinates or revising the existing coordinates.

### 3.2.5 Input Data – Time Stepping

If the user chooses to ask the program to estimate the soil subgrade stiffness based on the Young's modulus of the foundation soil, the program will estimate the soil stiffness using iterative procedures until the compatibility between the mat movement and soil stiffness converges. The process uses non-linear iteration for achieving the convergence and the user needs to specify the parameters associated with the iteration process shown in Figure 3.19.

If the user enters the soil stiffness and support externally, "Time Stepping" is not needed and may leave default values for this option.





Figure 3.19 Window screen for Input Data Menu – Time Stepping


### 3.2.6 Input Data – Soil Stiffness

This submenu is disabled as a default but may be enabled if the user chooses to ask the program to estimate the soil subgrade stiffness based on the Young's modulus of the foundation soil. The program will estimate the soil stiffness using iterative procedures until the compatibility between the mat movement and soil stiffness converges. The associated screen is shown in Figure 3.20. Option 1 does not consider soil stiffness. This is the default option. Users may also select option 2 to estimate soil stiffness using Vlasov approach. Corresponding input window is shown as in Figure 3.21. The Young's modulus at top and bottom can be different. The default initial gamma=1 works well for most cases. If soil depth is significantly high, the initial gamma can be greater than 1 and smaller than 5. Option 3 uses Mindlin equation to estimate soil stiffness (Figure 3.22). Mindlin's equations are also used to calculate the stress-strain behavior in the soil. The detailed iteration procedures are discussed in the Technical Manual.



The dialog box titled "Soil Stiffness" has a close button (X) in the top right corner. It contains three radio button options: "Do not consider Soil Stiffness" (selected), "Estimate Soil Stiffness using Vlasov Approach", and "Estimate Soil Stiffness using Mindlin Equation". To the right of these options are "OK" and "Cancel" buttons. Below the options is a group box containing three input fields: "Young Modulus" with the value "1000", "Poisson's Ratio" with the value "0.3", and "Initial Stiffness" with the value "500". A small 3D wireframe cube icon is located in the bottom right corner of the dialog box.

Figure 3.20 Window screen for Input Data Menu – Default option



The dialog box titled "Soil Stiffness" has a close button (X) in the top right corner. It contains three radio button options: "Do not consider Soil Stiffness", "Estimate Soil Stiffness using Vlasov Approach" (selected), and "Estimate Soil Stiffness using Mindlin Equation". To the right of these options are "OK" and "Cancel" buttons. Below the options is a group box containing five input fields: "Young Modulus at Top" with the value "1000", "Young Modulus at Bottom" with the value "1000", "Poisson's Ratio" with the value "0.3", "Soil Depth" with the value "10", and "Initial Gamma" with the value "1". A small 3D wireframe cube icon is located in the bottom right corner of the dialog box.

Figure 3.21 Window screen for Input Data Menu – Vlasov approach

Soil Stiffness

☐ Do not consider Soil Stiffness  
☐ Estimate Soil Stiffness using Vlasov Approach  
☒ Estimate Soil Stiffness using Mindlin Equation

Young Modulus: 1000  
 Poisson's Ratio: 0.3  
 Initial Stiffness: 500

OK Cancel

Figure 3.22 Window screen for Input Data Menu – Mindlin equation

### 3.2.7 Input Data – Element Type

This option allows the user to choose the type of element to be used in the analysis. There are three options: Linear 4-noded, Quadratic 8-noded, and Lagrangian 9-noded. If the **New from template** option is used, this choice is automatically made for the user.

### 3.2.8 Input Data – Element Connectivity

This selection launches the Element Connectivity window. This allows the user to define the nodes for each element number. If the **New from template** option is used, these values are automatically filled in for the user. The user can modify the data if an irregular shape is required for the meshes.

### 3.2.9 Input Data – Integration Points

This submenu allows the user to select either a reduced or normal integration procedure to be used for the analysis. For linear 4-noded elements, only one integration point in each element is available. Otherwise, the user can select 2x2 or 3x3 for the integration points.

### 3.2.10 Input Data – Nodal Constrains

This submenu item opens the Nodal Constraints dialog box, as shown in Figure 3.23. Here, the user inputs the node(s) where the restraint is located. Both translational and rotational restraints at nodal points may be restricted using this feature.

Node Number	Displacement X	Displacement Y	Displacement Z	Rotation X	Rotation Y	Rotation Z
1 LEFT	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input checked="" type="checkbox"/> 0
2 BOTTOI	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0
3 TOP	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0
4 RIGHT	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0

Number of Rows: 4

Figure 3.23 Window screen for Input Data Menu – Nodal Constraints

### 3.2.11 Input Data – Nodal Loads

This window allows the user to specify the location of a point load applied at a nodal point. A sample screen of this box is shown in Figure 3.24. The units for nodal loads are F.

Node Number	Force X	Force Y	Force Z	Moment X	Moment Y	Moment Z
1 1	<input checked="" type="checkbox"/> 0.25	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0

Number of Rows: 1

Figure 3.24 Window screen for Input Data Menu – Nodal Loads

### 3.2.12 Input Data – Nodal Stiffness

This window allows the user to specify the location of a concentrated stiffness applied at a nodal point. A sample screen of this box is shown in Figure 3.25. The units of nodal stiffness are F/L.

Node Number	Trans. K X	Trans. K Y	Trans. K Z	Rotat. K X	Rotat. K Y	Rotat. K Z
1 5	<input checked="" type="checkbox"/> 600	<input type="checkbox"/> 0	<input checked="" type="checkbox"/> 50	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
2 37	<input checked="" type="checkbox"/> 400	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
3 45	<input checked="" type="checkbox"/> 400	<input checked="" type="checkbox"/> 10	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input checked="" type="checkbox"/> 25

Buttons: OK, Cancel, Apply, Sort, Add Row, Insert Row, Delete Row, Number of Rows: 3

Figure 3.25 Window screen for Input Data Menu – Nodal Stiffness

### 3.2.13 Input Data – Distributed Loads

This option displays the window shown in Figure 3.26. The user may enter pressures which are distributed over an element or elements. Both distributed force (the units are  $F/L^2$ ) and distributed moment (the units of are  $F-L/L^2$ ) can be specified.


Element Number	D. Force X	D. Force Y	D. Force Z	D. Mom X	D. Mom Y	D. Mom Z
1 3	<input checked="" type="checkbox"/> 10	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0

Buttons: OK, Cancel, Apply, Sort, Add Row, Insert Row, Delete Row, Number of Rows: 1

Figure 3.26 Window screen for Input Data Menu – Distributed Loads

### 3.2.14 Input Data – Distributed Stiffness

This option displays the Distributed Stiffness input box, shown in Figure 3.27. The user may enter here stiffnesses which are distributed over an element or elements. Both rotational and translational stiffnesses can be specified. The units for distributed translational stiffness are  $F/L^3$ . The units for distributed rotational stiffness are  $F-L/Rad./L^2$ .




The 'Distributed Stiffnesses' window contains a table for inputting stiffness values for multiple elements. The table has columns for Element Number, D. Tr. K X, D. Tr. K Y, D. Tr. K Z, D. Rot K X, D. Rot K Y, and D. Rot K Z. The first row shows Element Number 1, D. Tr. K X checked and set to 10, and all other values set to 0. On the right side, there are buttons for OK, Close, Apply, Sort, Add Row, Insert Row, Delete Row, and a Number of Rows field set to 1. A small 3D mesh icon is located at the bottom right.

Element Number	D. Tr. K X	D. Tr. K Y	D. Tr. K Z	D. Rot K X	D. Rot K Y	D. Rot K Z
1	<input checked="" type="checkbox"/> 10	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0

Figure 3.27 Window screen for Input Data Menu – Distributed Stiffness

### 3.2.15 Input Data – Concentrated Loads

This option displays the window shown in Figure 3.28. The user may specify the exact coordinates of a point load which is not located at a nodal point. The units for concentrated force are F. The units for concentrated moment are F-L.



The 'Concentrated Loads' window contains a table for inputting coordinates and forces/moments for multiple points. The table has columns for Coord. X, Coord. Y, Coord. Z, Force X, Force Y, Force Z, Moment X, Moment Y, and Moment Z. The first four rows show coordinates (0, -7.6, 3.9), (0, 7.6, 3.9), (0, 7.6, -3.9), and (0, -7.6, -3.9) with corresponding forces (1.1, 1.09, 1.34, 1.11) and all moments set to 0. On the right side, there are buttons for OK, Cancel, Apply, Add Row, Insert Row, Delete Row, and a Number of Rows field set to 4. A small 3D mesh icon is located at the top left.

	Coord. X	Coord. Y	Coord. Z	Force X	Force Y	Force Z	Moment X	Moment Y	Moment Z
1	0	-7.6	3.9	1.1	0	0	0	0	0
2	0	7.6	3.9	1.09	0	0	0	0	0
3	0	7.6	-3.9	1.34	0	0	0	0	0
4	0	-7.6	-3.9	1.11	0	0	0	0	0

Figure 3.28 Window screen for Input Data Menu – Concentrated Loads

### 3.2.16 Input Data – Equivalent Concentrated Loads

This option displays the window shown in Figure 3.29. This option allows the user to place concentrated loads from anchor bolts of the mounting plate to the top of the foundation. The user can specify the number of circular rings for anchor bolt arrangement and the diameters of each ring. The user also needs to specify the loads (six-degree of loading) applied on the foundation through the anchor bolts.

The program will calculate the location of each anchor bolt arranged in a circular pattern and the distributed load on each anchor bolt based on the user-specified data.

**Loading**

Fx: 1108  
Fy: 0  
Fz: 0  
Mx: 0  
My: 21373.4  
Mz: 0

**Point of Application**

X: 0  
Y: 0  
Z: 0

**Number of Rings**

☐ One Ring  
☒ Two Rings

☐ Show Values

**Ring 1 Data**

Radius (ri): 1.839  
Points (ni): 48  
Angle (fi): 0

**Ring 2 Data**

Radius (re): 1.959  
Points (ne): 48  
Angle (fe): 0

**Equivalent Loads**

Ring	N	X	Y	Z	Fx
Int 1	1	0.000000	1.839000	0.000000	11.541667
Int 2	2	0.000000	1.823267	0.240038	41.150992
Int 3	3	0.000000	1.776338	0.475968	70.253694
Int 4	4	0.000000	1.699014	0.703755	98.351816
Int 5	5	0.000000	1.592621	0.919500	124.96459
Int 6	6	0.000000	1.458977	1.119512	149.63667
Int 7	7	0.000000	1.300369	1.300369	171.94590
Int 8	8	0.000000	1.119512	1.458977	191.51058
Int 9	9	0.000000	0.919500	1.592621	207.99593
Int 10	10	0.000000	0.703755	1.699014	221.11990
Int 11	11	0.000000	0.475968	1.776338	230.65793
Int 12	12	0.000000	0.240038	1.823267	236.44682
Int 13	13	0.000000	0.000000	1.839000	238.38752
Int 14	14	0.000000	-0.240038	1.823267	236.44682
Int 15	15	0.000000	-0.475968	1.776338	230.65793
Int 16	16	0.000000	-0.703755	1.699014	221.11990

**Visible Variables**

☒ X  
☒ Y  
☒ Z  
☒ Fx  
☒ Fy  
☒ Fz

OK Cancel Apply

Figure 3.29 Window screen for Input Data Menu – Equivalent Concentrated Loads

### 3.2.17 Input Data – Concentrated Stiffness

This option displays the Concentrated Stiffness input box, shown in Figure 3.30. The user may specify the exact location of a concentrated stiffness which is not located at a nodal point. The units of concentrated translation stiffness are F/L. The units of concentrated rotational stiffness are F-L/Radian.

**Concentrated Stiffnesses**

	Coord. X	Coord. Y	Coord. Z	Tra. K	Tra. K	Tra. K	Rot. K	Rot. K	Rot. K
1	0	5	2	0.200	0	0	0	0	0

OK  
Cancel  
Apply

Add Row  
Insert Row  
Delete Row  
Number of Rows: 1

Figure 3.30 Window screen for Input Data Menu – Concentrated Stiffness

### 3.2.18 Input Data – Edge Load

This option displays the Edge Load input box, shown in Figure 3.31. The user may enter a line load to be evenly distributed along an edge.

Element: the user can select a single element or a group of elements with the same edge stiffness (see Input Data - Element Set).

Side No.: each element may have 3 sides or 4 sides. The user needs to specify which side with the edge stiffness.

DOF Index: there are 6 degrees of freedom on each edge node. The degree freedom index is 1 for translation in X direction, 2 for translation in Y direction, 3 for translation in Z direction, 4 for rotation about X axis (not available in this program), 5 for rotation about Y axis, and 6 for rotation about Z axis.

Load Node 1: each side of an element usually has either 2 nodes or 3 nodes. Load Node 1 is for one of the edge nodes. Enter the load (based on the DEF index) on this nodal point.

Load Node 2: each side of an element usually has either 2 nodes or 3 nodes. Load Node 2 is for the other one of the edge nodes. Enter the load (based on the DOF index) on this nodal point.

Load Node 3: each side of an element usually has either 2 nodes or 3 nodes. Stiff Node 3 is for the middle node if a quadratic element is used. Enter the load (based on the DEF index) on this nodal point.

The units for edge translation load are F/L. The units for edge bending moment are F-L/ L.

Element	Side	DOF	Load Node 1	Load Node 2	Load Node 3
1	WALL	0	1	0.6	0.6

Figure 3.31 Window screen for Input Data Menu – Edge Load

### 3.2.19 Input Data – Edge Stiffnesses

This option displays the Edge Stiffnesses input box, shown in Figure 3.32. The user may enter stiffnesses which are distributed along an element edge.

Element: the user can select a single element or a group of element with the same edge stiffness (see 3.2.21 Input Data – Edge Sets).

Side No.: each element may have 3 sides or 4 sides. The user needs to specify which side with the edge stiffness.

DOF Index: there are 6 degrees of freedom on each edge node. The degree freedom index is 1 for translation in X direction, 2 for translation in Y direction, 3 for translation in Z direction, 4 for rotation about X axis (not available in this program), 5 for rotation about Y axis, and 6 for rotation about Z axis.

Stiff Node 1: each side of an element usually has either 2 nodes or 3 nodes. Stiff Node 1 is for one of the edge nodes. Enter the translation or rotational stiffness (based on the DEF index) on this nodal point.

Stiff Node 2: each side of an element usually has either 2 nodes or 3 nodes. Stiff Node 2 is for the other one of the edge nodes. Enter the translation or rotational stiffness (based on the DEF index) on this nodal point.

Stiff Node 3: each side of an element usually has either 2 nodes or 3 nodes. Stiff Node 3 is for the middle node if quadratic element is used. Enter the translation or rotational stiffness (based on the DEF index) on this nodal point.

The units for edge translation stiffness are  $F/L^2$ . The units for edge rotational stiffness are  $F\cdot L/Rad./L$ .

	Element	Side	DOF	Stiff. Node 1	Stiff. Node 2	Stiff. Node 3
1	ALL	2	3	0	0	60
2	WALL	2	3	0	0	300

Number of Rows: 2

Figure 3.32 Window screen for Input Data Menu – Edge Stiffnesses

### 3.2.20 Input Data – Node Sets

This window, shown in Figure 3.33, allows the user to define groups of nodes. This option facilitates the assignment of nodal properties by grouping nodes together into node sets. The user enters an alpha-numeric name for the set, then selects the nodes to be placed in that group. To use a defined node set, the name of the node set is entered in lieu of the node number. By default, the set ALL is defined as the node set containing all of the nodes in the slab.

To select the nodes to be included in a named group, click the Define button. This opens the screen shown in Figure 3.34. Using the Add Row button, enter the range of nodes to be added to the set. For greater ease in selecting nodes, use the **Selection - Select Node** function to “point and click” on the desired nodes.




Figure 3.33 Window screen for Input Data Menu – Node Sets




Figure 3.34 Window screen for selecting nodal points under Input Data Menu – Node Sets

### 3.2.21 Input Data - Element Set

This window, shown in Figure 3.35, allows the user to define groups of elements. This option facilitates the assignment of element properties by grouping elements together into element sets. The user enters an alpha-numeric name for the set, then selects the elements to be placed in that group. To use a defined element set, the name of the element set is entered in lieu of the element number. By default, the set ALL is defined as the element set containing all of the elements in the slab.

To select the elements to be included in the group, click the Define button. This launches a window similar to that seen in Figure 3.36. For greater ease in selecting elements, use the **Selection - Select Element** function to “point and click” on the desired elements.




Figure 3.35 Window screen for Input Data Menu – Element Sets




Figure 3.36 Window screen for selecting nodal points under Input Data Menu – Element Sets

### 3.2.22 Input Data – Edge Sets

This window, shown in Figure 3.37, allows the user to define groups of element edges. This option facilitates the assignment of edge properties by grouping edges together into edge sets. The user enters an alpha-numeric name for the set, then selects the edges to be placed in that group. To use a defined edge set, the name of the edge set is entered in lieu of the element and edge number. By default, the set ALL is defined as the set containing all of the edges in the slab.




Figure 3.37 Window screen for sample Input Data Menu – Edge Sets

To select the edges to be included in a named group, click the **Define** button. This opens the screen shown in Figure 3.38. Using the Add Row button, enter the edges to be added to the set. For greater ease in selecting edges, use the Selection – Select Edge function to “point and click” on the desired edges.




Figure 3.38 Window screen for selecting edges for Input Data – Edge Sets

### 3.2.23 Input Data – Section Cut

Section cut is a useful tool to plot stress components along one or more straight cut lines. The input interface is shown as in Figure 3.39.

1. Number of sample division of each segment.

When one cut line passes through the region of a mesh element, it will be divided into several line segments by intersected elements. The default segment division is 4 with equal spaces. Outputs are given at 5 points: two locate on finite element edges, three locate inside this element. The default division number can be modified by user.

2. Source of stress points:

Two options are available to select the stress source for interpolation. Option one use stresses from Gaussian integration points. Another option uses stresses at the nodal position.

Generally, stresses are accurate at Gaussian integration points. The nodal values are averaged from adjacent elements and are less accurate. But at region with sharp deformation gradient, stresses are often not continuous from one element to another. Using the nodal value option is helpful to smooth the curve plot.

3. Define cut lines

The user inputs the end coordinates to define one cut line. Two default cut lines are defined automatically: one horizontal and one vertical. Both default cut lines pass through the origin point (0, 0). Note that the coordinates of end nodes of one cut line shall locate outside of the plate.

The 'Section Cut' dialog box is shown with the following settings:

- Interpolation Option:** Integration Point (selected), Node (unselected).
- Segment division:** 4.
- Start Point:**
  - coordinate y: -5.5
  - coordinate z: 0
- End Point:**
  - coordinate y: 5.5
  - coordinate z: 0

Buttons: OK, Cancel, Apply, Add Cut Line, Del Cut Line.

Figure 3.39 Window screen for sample Input Data Menu – Section Cut

The cut line can be horizontal, vertical or in an arbitrary angle. Section cut results can be found from the output file \*.sou. One sample is shown in Figure 3.40:

Section cut output

Cut line=	1	Start at point: y=	-5.1000	z=	0.0000	End at point: y=	5.1000	z=	0.0000			
Element	S	Deflection	Theta_y	Theta_z	My	Mz	Myz	Q_xy	Q_xz			
181	0.0000E+00	0.0000E+00	0.1343E-20	-0.1430E-04	-0.1018E+01	-0.2250E+01	0.1340E+00	-0.2062E+02	0.9410E+01			
181	0.1250E+00	0.1799E-05	0.1187E-20	-0.1428E-04	-0.1156E+01	-0.2321E+01	0.1217E+00	-0.2028E+02	0.6337E+01			
181	0.2500E+00	0.3598E-05	0.1031E-20	-0.1426E-04	-0.1295E+01	-0.2392E+01	0.1095E+00	-0.1993E+02	0.3263E+01			
181	0.3750E+00	0.5398E-05	0.8753E-21	-0.1424E-04	-0.1433E+01	-0.2462E+01	0.9728E-01	-0.1959E+02	0.1890E+00			
181	0.5000E+00	0.7197E-05	0.7195E-21	-0.1422E-04	-0.1572E+01	-0.2533E+01	0.8505E-01	-0.1925E+02	-0.2885E+01			
182	0.5000E+00	0.7197E-05	0.7195E-21	-0.1422E-04	-0.1572E+01	-0.2533E+01	0.8505E-01	-0.1925E+02	-0.2885E+01			
182	0.6250E+00	0.9216E-05	0.1152E-20	-0.1413E-04	-0.1901E+01	-0.2916E+01	0.8801E-01	-0.1871E+02	-0.1420E+01			
182	0.7500E+00	0.1123E-04	0.1585E-20	-0.1404E-04	-0.2230E+01	-0.3299E+01	0.9097E-01	-0.1817E+02	0.4531E-01			
182	0.8750E+00	0.1325E-04	0.2018E-20	-0.1395E-04	-0.2559E+01	-0.3682E+01	0.9392E-01	-0.1764E+02	0.1510E+01			
182	0.1000E+01	0.1527E-04	0.2451E-20	-0.1386E-04	-0.2888E+01	-0.4064E+01	0.9688E-01	-0.1710E+02	0.2975E+01			
183	0.1000E+01	0.1527E-04	0.2451E-20	-0.1386E-04	-0.2888E+01	-0.4064E+01	0.9688E-01	-0.1710E+02	0.2975E+01			
183	0.1125E+01	0.1671E-04	0.2585E-20	-0.1374E-04	-0.3139E+01	-0.4536E+01	0.9802E-01	-0.1747E+02	0.1302E+01			
183	0.1250E+01	0.1814E-04	0.2720E-20	-0.1363E-04	-0.3389E+01	-0.5007E+01	0.9916E-01	-0.1784E+02	-0.3709E+00			
183	0.1375E+01	0.1958E-04	0.2854E-20	-0.1352E-04	-0.3639E+01	-0.5479E+01	0.1003E+00	-0.1821E+02	-0.2044E+01			
183	0.1500E+01	0.2102E-04	0.2988E-20	-0.1341E-04	-0.3890E+01	-0.5950E+01	0.1014E+00	-0.1859E+02	-0.3717E+01			
184	0.1500E+01	0.2102E-04	0.2988E-20	-0.1341E-04	-0.3890E+01	-0.5950E+01	0.1014E+00	-0.1859E+02	-0.3717E+01			
184	0.1625E+01	0.2322E-04	0.2377E-20	-0.1326E-04	-0.4187E+01	-0.6457E+01	0.1022E+00	-0.1921E+02	-0.1880E+01			
184	0.1750E+01	0.2543E-04	0.1766E-20	-0.1311E-04	-0.4485E+01	-0.6965E+01	0.1029E+00	-0.1984E+02	-0.4263E-01			
184	0.1875E+01	0.2764E-04	0.1154E-20	-0.1297E-04	-0.4783E+01	-0.7472E+01	0.1037E+00	-0.2047E+02	0.1795E+01			

where “S” is the distance to the most left or top mesh edge.

Figure 3.40 Sample of output data from Edge Sets option

Default color for the cut lines is blue. The cut line that is selected will be highlighted in red as in Figure 3.41. Users can edit the coordinates of the start/end point of a cut line. Then click **Apply** to make it effective.

Default two cut lines can not be edited or deleted.




Figure 3.41 Window screen showing cutting sections by using Input Data Menu – Section Cut

## **CHAPTER 4.      Finite Element Mesh Adjustment**

## 4.1 Introduction

Capability of mesh adjustment is added into version *GeoMat* 2022. Users may refine current mesh for better convergence performance or make mesh coarser to reduce computing time. However, this operation may delete previously defined materials, loads, constraints or stiffnesses. Users shall check consistency before the new analysis.

## 4.2 Mesh Refinement

The mesh refinement option is incorporated into the Edit menu as shown in Figure 4.1. Based on the template used to build previous mesh, a different interface window will prompt. If previous mesh is built from conventional circular/rectangular plate template, the mesh refinement window will look like that Figure 4.2. The default refinement factor for both y and z directions are set to 2 which means element number in y and z directions will be doubled. Refinement factor should be an integer. Any float number will be round up to an integer. If the refinement factor is smaller than 1, no new mesh is regenerated. If users set the division in one direction to be 1, there will be no mesh refinement in that direction.

Note this refinement approach is also applicable to unequally spaced mesh.






Figure 4.1 Mesh adjustment options contained in the Edit menu

Click button **OK** to close mesh refinement window. A message window will pop up to remind users to check consistency because previous boundary conditions or materials may be not available (Figure 4.3). If **Yes** is clicked, new mesh will be generated as shown in Figure 4.4.



**Figure 4.2 Mesh adjustment for conventional circular/rectangular plate**



**Figure 4.3 Information message before mesh adjustment is processed**

If previous mesh is built from the template of octagon/circular wind turbine foundation, the mesh refinement input window will look like that in Figure 4.5. Users may change the typical finite element size to a new value for the new mesh. Previous geometry data and load data will be kept and convert to new mesh. Users still should check consistency of materials, node constrains or other boundary conditions defined in previous mesh.




Figure 4.4 Refined mesh in both y and z directions




Figure 4.5 Refine mesh for wind turbine foundation

### 4.3 Change of Element Type

It is recommended in *GeoMat* to use quadratic eight-node element combined with 2x2 integration rule. This element type provides good accuracy and efficiency so that it is appropriate for most cases. If another element type is desired, users may click menu **Edit->Change Element Type** and select another one. If quadratic eight-node is the current element type, only conversion to linear four-node or Lagrangian nine-node element type is available. A message window will pop up to remind users to check consistency after conversion (Figure 5.7). Since converting to a new element type will regenerate the mesh, all previously defined boundaries/materials may be invalid. After a successful conversion, nodes will be highlighted in red as in Figure 4.8. Click **Options->Mark Nodes** to disable node mark.




Figure 4.6 Change element type from Edit menu




Figure 4.7 Information message before change of element type is processed




Figure 4.8 Mesh after change of element type from 8-node to 4-node

## 4.4 Change of Integration Rule

Default integration rules in *GeoMat* are defined as following:

- 1x1 or 2x2 are available to four-node element. 2x2 is recommended
- 2x2 or 3x3 are available to eight-node element. 2x2 is recommended
- 3x3 is available to nine-node Lagrangian element. It is the only integration rule for this element type.

Users may change integration rule by clicking menu **Edit->Input Data->Integration Points** then select one rule (Figure 5.9). Changing integration does not regenerate the mesh. Previously defined material, boundaries, various sets can be kept.




Figure 4.9 Change integration rule from Edit menu

## **CHAPTER 5.      Program Execution and Output Reviews**

## 5.1 Introduction

Chapter 4 presents options related to execution of the program and includes methods of addressing run-time errors. This chapter also includes suggestions for reviewing input, output, and processor text files. The final section of this chapter includes descriptions about the slab properties that may be observed in graphical form. The commands covered in this chapter are contained in the top menu, under the **Computation** and the **Results** titles.

## 5.2 Computation Menu

This menu is used to execute the program with the parameters that were saved in the input-data file. Within the options contained under this menu, shown in Figure 5.1, there are commands that facilitate the reviews of the text files produced for storing input data, output results, and processor notes. Detailed description of the submenu options contained under the **Computation** menu is explained in the following sections.




Figure 5.1 Options contained in the Computation menu

### 5.2.1 Computation- Run Analysis

An input file, after preparation or modification, must be saved to disk before selecting the **Computation -Run Analysis** submenu option, which executes the analytical portion of program *GeoMat*. The module, a stand-alone program routine, is called for execution by the “shell” process of the environment in Microsoft Windows<sup>®</sup>.

**The user should remember to save the input data under a user-specified name before executing the analytical module.** When saving data to disk, *GeoMat* will automatically add an extension of the type *\*.slb* to the name of the input file. A sub-window is usually produced during the execution of the module. A finished execution of the module is determined when the sub-window closes.

At the beginning of the run, the analytical module will read the saved input data progressively, showing the line number which is being read. If an input-data format is incorrect during reading, the analytical module will stop immediately and in many cases, it saves an error message and a status report in a file with the extension *\*.sms*. This file may be accessed by selecting **View Message File** in the **Computation** menu.

Within the processor-run notes, if all input data was read correctly, the analytical module will show the ending time of the analysis. The analytical module automatically creates an output file with the same name as the input and with the extension *\*.sou*. Once a successful run is produced, the user may proceed to the next items for observation of results.

### 5.2.2 Computation- View Input File

This submenu option is used to edit the input-data file in plain text mode. This command becomes active after new data files have been saved to disk or when opening existing data files. The command is helpful for experienced users who may just want to change one or two parameters quickly using the text editor, or for those users wishing to observe the prepared input data in text mode. This submenu automatically invokes a text editor. The default setting is to use the utility program named *notepad.exe* provided by Microsoft Windows<sup>®</sup>. Input-data text files are automatically saved to disk with the extension of *\*.sin* by program *GeoMat*. Use of the notepad for editing the input data for Example Problem 1 is shown in Figure 5.2.

### 5.2.3 Computation- View Output File

This submenu option is used to edit the output-text file that is automatically produced during each analytical run. This command becomes active after new data files have been saved to disk and successfully executed, or when opening previously-executed data files.

The submenu automatically invokes a text editor. The default setting is to use the utility program named *notepad.exe* provided by Microsoft Windows<sup>®</sup>. Output files are automatically saved to disk with the same file name as the input-data file but with the extension *\*.sou*. Use of Microsoft Notepad<sup>®</sup> for editing the output file for Example Problem 1 is shown in Figure 5.3.

```

example1.slb - Notepad
File Edit Format View Help
TITLE
Example 1
UNIT_DATA
*
0
END_UNIT_DATA
NODE_DATA
*
1      0      -5      5
*
2      0      0      5
*
3      0      5      5
*
4      0      -5      0
*
5      0      5      0
*
6      0      -5      -5
*
7      0      0      -5
*
8      0      5      -5
END_NODE_DATA
MATERIAL_DATA
*
ALL      0      10000      20000      0.3      0.2
END_MATERIAL_DATA
ELEMENT_DATA
QUAD8      REDUCED_INTEGRATION
1      1      1      3      8      6      2      5      7      4
END_ELEMENT_DATA
NODAL_CONSTRAINT_DATA
*
1      0      0      0      1      0      1      0      0      0      0
*
3      0      0      0      1      0      1      0      0      0      0
*
4      0      0      0      1      0      1      0      0      0      0
*
5      0      0      0      1      0      1      0      0      0      0
*
6      1      0      0      1      1      1      0      0      0      0
*
7      1      0      0      1      1      1      0      0      0      0
*
8      1      0      0      1      1      1      0      0      0      0
END_NODAL_CONSTRAINT_DATA
NODAL_LOAD_DATA
*
1      1      0      0      0      0      0      0.01      0      0      0      0
*
2      1      0      0      0      0      0      0.04      0      0      0      0
*
3      1      0      0      0      0      0      0.01      0      0      0      0
END_NODAL_LOAD_DATA
TIME STEPPING_DATA
1      0      1      1      10      0.0001
END_TIME STEPPING_DATA
NODESET_DATA
*
ALL

```

Figure 5.2 Sample use of Microsoft Notepad for editing input text of Example Problem 1.

#### 5.2.4 Computation- View Message File

This submenu option is used to edit an intermediate text file that is automatically produced during each analytical run. This file only includes notes produced during the processing of the input data. This submenu option becomes active after new-data files have been saved to disk and executed, or when opening previously executed data files. This submenu automatically invokes a text editor. The default setting is to use the utility program named *notepad.exe* provided by Microsoft Windows<sup>®</sup>.

Files containing processor-run notes are automatically saved to disk with the same file name as the input-data file but with the extension *\*.sms*. Using of the Microsoft Notepad<sup>®</sup> for editing the processor-run notes for Example Problem 1 is shown in Figure 5.4. Observation of the notes produced during a processor run may become helpful to debug a data file that did not produce a successful run. A successful run usually produces a file of processor-run notes containing similar lines of text as those in Figure 5.4.

```

example1.sou - Notepad
File Edit Format View Help
Example 1

npoin = 8      nele = 1      nvfix = 7      ncase = 1      ntype = 0      nnode = 8      ndofn = 6
nmats = 1      nprop = 3      ngaus = 2      ngaus2 = 2      ndime = 3      nstre = 8      newab = 48
nnlod = 3      nnsti = 0      ndlod = 0      ndsti = 0      nclod = 0      ncsti = 0      nctsti = 0
dt = 1.0000    tini = 0.0000    tend = 1.0000    dtmin = 1.0000    maxiter = 10

element  material
      1      1      1      2      3      4      5      6      7      8
      1      1      1      3      8      6      2      5      7      4

nodal point coordinates
node      x      y      z
1      0.0000      -5.0000      5.0000
2      0.0000      0.0000      5.0000
3      0.0000      5.0000      5.0000
4      0.0000      -5.0000      0.0000
5      0.0000      5.0000      0.0000
6      0.0000      -5.0000      -5.0000
7      0.0000      0.0000      -5.0000
8      0.0000      5.0000      -5.0000

restrained nodes
node      dof      fixed values
1      000101      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
3      000101      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
4      000101      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
5      000101      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
6      100111      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
7      100111      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00
8      100111      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00      0.00000E+00

material properties

```

Figure 5.3 Sample use of Microsoft Notepad for view output text of Example Problem 1.

### 5.3 Results Menu

This menu option is selected to observe the different graphical representations of the program results contained in the output file. Submenu options contained under this menu are shown in Figure 5.5. All the graphical representation of output data that may be produced by the program are contained in the following commands of the **Results** menu:


**Select Step**

**Deformed Mesh**

**Contour Plot**

**Selection Cut Plot**

The observation of any of the above-listed options will activate the graphics mode of *GeoMat*. Several changes occur during use of the graphics mode: new mouse commands are enabled and a new top-menu option becomes available.



```

example1.sms - Notepad
File Edit Format View Help
4/15/2014
16:44:40:98

step      1   tcur   =    1.0000   dt =    1.0000
iter =    1  err1 = 0.1000E+01 d = 0.4882E+00 u = 0.4882E+00 rhs = 0.4243E-01
        err2 = 0.1000E+01 r = 0.8317E-01 ru= 0.8317E-01 rrhs= 0.0000E+00
iter =    2  err1 = 0.1097E-11 d = 0.5357E-12 u = 0.4882E+00 rhs = 0.4243E-01
        err2 = 0.1181E-11 r = 0.9826E-13 ru= 0.8317E-01 rrhs= 0.4347E+00
Execution time 0.2370000 seconds.
This includes 0.2370000 seconds of user time and
              0.0000000E+00 seconds of system time.
4/15/2014
16:44:41:19
    
```

Figure 5.4 Sample use of Microsoft Notepad for view message file of Example Problem 1.




Figure 5.5 Command options contained in Result menu

### 5.3.1 Results – Select Step

The user may select this command option to observe a graphical representation of the time steps used to compute the solution. A sample screen of the **Select Step** command option is shown in Figure 5.6. This is ideally used in conjunction with the other two available menu options, **Deformed Mesh** and **Contour Plot**.




Figure 5.6 Sample screen of the Select Step command option

### 5.3.2 Results – Deformed Mesh

The user may select this command option to observe a graphical representation of the deformed shape for the modeled slab. A sample screen of the **Deformed Mesh** command option is shown in Figure 5.7. The shape factor for the amount of deformation may be varied by the user. The user also may choose to display undeformed shapes together with the deformed shape, as seen in Figure 5.8




Figure 5.7 Sample screen of the Deformed Mesh command option




Figure 5.8 Combined display of deformed and undeformed configuration

### 5.3.3 Results – Contour Plot

The user may select this command option to observe a contour plot of the output on the surface of the slab model. A sample screen of the **Contour Plot** command option is shown in Figure 5.9. The user may choose from a variety of contour distributions: displacement, rotation, moment, shear, and stress. The user may select the default contour limits or modify them. Contour types available are shading, lines, and shading and lines together. Figure 5.10 demonstrates the appearance of the line contour option, and Figure 5.11 the shading contour option for vertical displacement. Figure 5.12 and Figure 5.13 demonstrate the shading contour option for moment and stress distributions, respectively.




Figure 5.9 Sample screen of the Contour Plot command option




Figure 5.10 Line contour option for vertical displacement in Contour Plot




Figure 5.11 Shading contour option for vertical displacement in Contour Plot




Figure 5.12 Shading contour option for moment distribution in Contour Plot




Figure 5.13 Shading contour option for stress distribution in Contour Plot

### 5.3.4 Results – Section Cut Plot

The user may select this command to plot plate forces along one pre-defined cut line as shown in Figure 5.14. Different cut lines can be selected from the box under Cut Line Selection. Variables can be selected from variable box locating on the right side. Users can also change line color or line width.




Figure 5.14 X-Y plot for plate forces along one cut line

### 5.3.5 Results – Nodal Result

The user may select this command to plot deformation, reaction, plate forces or plate stresses for one specific node (Figure 5.15). Node number can be changed by clicking the small arrow or input a new node number directly. Select variable type button can switch between various output types.

Figure 5.15 Nodal output

## 5.4 Speed Buttons in Graphics Mode

The user is provided with a set of speed buttons available in the View toolbar, which is associated with the commands in the **Transform** menu. Submenu choices, in order of their appearance in the speed button toolbar (Figure 5.16), are briefly described below.

- Panning** ..... this function allows the slab model to be moved in the window.
- Rotate** ..... this function allows the slab model to be rotated around the origin.
- Zoom In/Out** ..... this function zooms in and out on the slab model.
- Restart** ..... this function resets the view to the original YZ plane view.
- YZ View (Top)** ..... this orients the slab in the YZ plane, looking at the top of the slab. This is demonstrated in Figure 5.17.
- YZ View (Bottom)** ..... this orients the slab in the YZ plane, looking at the bottom of the slab. This is demonstrated in Figure 5.18.
- XY View (Front)** ..... this orients the slab in the XY plane, looking at the front of the slab. This is demonstrated in Figure 5.19.
- XZ View (Side)** ..... this orients the slab in the XZ plan, looking at the side of the slab. This is demonstrated in Figure 5.20.
- XYZ View (3D View)** . this orients the slab in an orthographic 3D view. This is demonstrated in Figure 5.21.
- Rotation Angles** ..... this option allows the user to specify the desired rotation angle. The input window is shown in Figure 5.22.




Figure 5.16 Speed Buttons for graphics manipulation




Figure 5.17 Slab model displayed using the YZ View (Top) speed button




Figure 5.18 Slab model displayed using the ZY View (Bottom) speed button




Figure 5.19 Slab model displayed using the XY View (Front) speed button




Figure 5.20 Slab model displayed using the XZ View (Side) speed button




Figure 5.21 Slab model displayed using the XYZ View (3D View) speed button




Figure 5.22 Sample screen of the Rotation Angles command option

## **CHAPTER 6.      Examples**

## 6.1 Introduction

The chapter presents several examples studied by using *GeoMat*. In order to assure accuracy from the computer results, some examples have been compared with the results from close-form solutions or calculated by other analytical tools presented in the technical literature. Although examples presented in this chapter validate the output generated by this software, no warranty, expressed or implied, is offered as to the accuracy of results from the program. The program should not be used for design unless caution is exercised in interpreting the results and independent calculations are helpful to verify the general correctness of the results.

There are three types of output data provided by the computer. The first type is the output file giving the formatted text that consists of an echo-print of the input data, nodal coordinates, boundary constraints, load distributions, deflection at each nodal point, and, most of all, the bending moment and stress distribution at the integration points of each element.

The second type of output presents the data for a graphics file that allows the code to produce plots. All of the data are saved with ASCII format and mainly for internal use to present the graphics and contour plots based on the user's selection. The third type of output presents the status of execution with the user's data. It contains information about the iteration number, convergence condition, and the information about unsuccessful computation.

Example problems provide the user information on input and output of various cases and present a quick tutorial for real-world applications. The user is encouraged to study these examples and, with modifications, may even use them to solve similar problems. However, by no means can these limited examples explore the full functions and features provided by *GeoMat*.

## 6.2 Example 1: Cantilevered square plate simulated by single quadratic element

### 6.2.1 Problem Description

A square cantilever plate is modeled by a single 8-node isotropic plate element. Rotational restraints in the z direction are applied to nodes 1, 3, 4, and 5. Along the restrained edge, nodes 6, 7, and 8, translations in the x direction as well as rotational restraints in the y and z directions are applied. The length in the y and z direction is 10 in. and the thickness of the plate is 0.2 in. Young's modulus is taken as 10,000 kip/in<sup>2</sup> (ksi) and Poisson's ratio as 0.3. To model a uniform edge load, concentrated loads of P, 4P, and P are applied in the x direction at nodes 1, 2, and 3, where P = 0.01kip.

### 6.2.2 Modeling Instruction

To model this slab in *GeoMat*, first go to **File -> New from template**. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and "Quadratic 8 Noded" for the Element Type. Enter the "Length" and "Width" as 10, and the "Number of Divisions" as 1. Click **OK** to draw the slab on the screen (Figure 6.1).

Go to **Input Data -> Title** and enter a name for the current project. The name used here is *Example 1*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default “Element Number/Set” value as **ALL**, select **Isotropic** under “Material Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to those given in the problem statement and then click **OK** to save the changes and close the dialog box. In the Material Data Dialog box click **OK** to return to the main screen.

Before setting the nodal constraints and loads, it is recommended that the node numbers and marks are turned on. To do so, go to menu **Options -> Mark Nodes** and **Options -> Node Numbers**. Now that the nodes are marked, return to the **Input Data** menu, and select **Nodal Constraints**. Use the **Add Row** button to create a new line. In the Node Number column, enter the first node, 1. Check the box in the “Rotation Z” column to restrain the rotations in the z direction. Repeat for nodes 3, 4, and 5. For nodes 6, 7, and 8, check the “Displac. X”, “Rotation Y”, and “Rotation Z” columns. Click **Apply** and then **OK**. Next, proceed to the **Input Data** menu and select **Nodal Loads**. To set the load of 0.01kip to node 1, click **Add Row**, check the box next to the “Force X” column to activate the input box, and enter 0.01 in the Input box. For node 2, enter 0.04 in the “Force X” column and for node 3 enter 0.01. Click **Apply** and then **OK**. Figure 6.2 shows the slab with applied load and the nodal constraints, which can be obtained by going to the **Options** menu and select **Nodal Constraint** and **Nodal Loads**.




Figure 6.1 Example 1 slab, shown with marked and labeled nodal points




Figure 6.2 Example 1 slab shown with nodal constraints and nodal loads

Before executing the file, go to **File -> Save As...** and save the file as example1.slb. Once this is completed, go to menu **Computations -> Run Analysis** to launch the analysis. When the analysis is completed, go to menu **Computations -> View Output File**.

### 6.2.3 Output Results Review

When the analysis is completed, go to menu **Computations -> View Output File**. Figure 6.3 shows part of the result file. This output compares well to the results given in the text *Finite Elements for Structural Analysis* for this problem.

#### Displacements

Node	Disp X	Disp Y	Disp Z	Rot. X	Rot. Y	Rot. Z
1	0.273094E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.409500E-01	0.000000E+00
2	0.273094E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.409500E-01	0.110496E-13
3	0.273094E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.409500E-01	0.000000E+00
4	0.853593E-01	0.000000E+00	0.000000E+00	0.000000E+00	0.307125E-01	0.000000E+00
5	0.853593E-01	0.000000E+00	0.000000E+00	0.000000E+00	0.307125E-01	0.000000E+00
6	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
7	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00
8	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00

#### Reactions

Node	Force X	Force Y	Force Z	Moment X	Moment Y	Moment Z
1	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	-0.176148E-12
3	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	-0.293655E-12
4	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.600000E-01
5	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	0.000000E+00	-0.600000E-01
6	-0.100000E-01	0.000000E+00	0.000000E+00	0.000000E+00	-0.100000E+00	0.300000E-01
7	-0.400000E-01	0.000000E+00	0.000000E+00	0.000000E+00	-0.400000E+00	0.642866E-12
8	-0.100000E-01	0.000000E+00	0.000000E+00	0.000000E+00	-0.100000E+00	-0.300000E-01

Figure 6.3 Review output file example1.sou for displacement results

Figure 6.4 shows the deformed shape of the slab. This graphic is produced using the **Results -> Deformed Mesh** option. In the Deformed Shape dialog box check the “Show Deformed Shape” and “Show Undeformed Model” boxes then, set the “Deformed Shape Factor” to 5 and click **Apply**. To display the contour plot, open the **Results -> Contour Plot** window. Under “Contour Variable” select “Disp X,” and then click **Apply**. This output compares well to the results given in the text *Finite Elements for Structural Analysis* for this problem.




Figure 6.4 Example 1 slab shown with nodal constraints and nodal loads

## 6.3 Example 2: Fixed square plate subject to concentrated force at center

### 6.3.1 Problem Description

This example models a fixed, square plate using eight-node isotropic plate elements with a concentrated load  $P$  applied at the center. Taking advantage of symmetry, only a quarter of the plate will be modeled in this example.

Due to symmetry, restraints against rotations in the  $z$  direction are taken along an edge parallel to the  $z$  axis, and restraints against rotations in the  $y$  direction are taken along an edge parallel to the  $y$

axis. The fixed boundary is restrained against all translations and rotations. The length of the quarter plate is 8 in. in both the y and z direction, with a thickness of 0.25 in., and is divided into a 4x4 network. Young's modulus is 30,000 ksi and Poisson's ratio is 0.3. The center load, P, is 1 kip; however, due to symmetry, the load applied to the edge node will be 0.25 kip. Figure 6.5 shows the configuration of the nodal constraints on the slab.




Figure 6.5 Quarter model of fixed edge slab with center load

### 6.3.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select “Circular or Rectangular Conventional” and click **Next**. In the Template dialog box, choose “Rectangular – Equally Spaced” for the Shape and “Quadratic 8 Noded” for the Element Type. Enter the “Length” and “Width” as 8, and the “Number of Divisions” as 4. Click **OK** to draw the slab on the screen.

Go to menu **Input Data -> Title** and enter a name for the current project; here it is *Example 2*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default “Element Number/Set” value as **ALL**, select **Isotropic** under “Material Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to those given in the problem statement and then click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.

Before setting the nodal constraints and loads, it is recommended that the node numbers and marks are turned on. To do so, go to menu **Options -> Mark Nodes** and **Options -> Node Numbers**.

In addition, it is helpful to define node sets to aid in the assigning of restraints and loads. For this problem, four nodal sets were created using the **Input Data -> Node Sets** dialog. To create the first node set, click on the **Add Row** button. Enter the name **BOTTOM** into the edit box and click the **Define** button to launch the Node Set dialog. Using the **Add Row** button, enter 1 under “Node Number/Set,” 8 under “Final” and 1 under “Increment” to select the nodes to be defined in this nodal set (nodes 1 through 8). For nodal set **LEFT**, nodes 1, 10, 15, 24, 29, 38, 43, and 52 are defined. One way to input this data is by adding 2 rows. For the first row, enter 1 under “Node Number/Set,” 43 under “Final” and 14 under “Increment.” For the second row, enter 10 under “Node Number/Set,” 52 under “Final” and 14 under “Increment.” For nodal set **TOP**, nodes 57 through 65 are defined. For nodal set **RIGHT**, nodes, 9, 14, 23, 28, 37, 42, 51, and 56 are defined. Click **OK** to save these settings, as shown in Figure 6.6.

Now that the nodes are marked and node sets defined, return to the **Input Data** menu, and select **Nodal Constraints**. Use the **Add Row** button to create a new line. In the Node Number column, enter the name of one of the nodal sets. As seen in Figure 6.5, nodal set **BOTTOM** corresponds to a rotational restraint in the y direction. Check the box in the “Rotation Y” column to restrain the rotations in the y direction. The nodal set **LEFT** corresponds to a rotational restraint in the z direction. Check the box in the “Rotation Z” column to restrain the rotations in the z direction. The nodal sets **TOP** and **RIGHT** are fixed in all directions. Check all the boxes to restrain displacements and rotations in all direction. Use Figure 6.5 as a guide. Click **Apply** and then **OK**. Next, proceed to menu **Input Data -> Nodal Loads**. To set the load of 0.25 kip to node 1, the center node, click **Add Row**, enter 1 under “Node Number,” check the box next to the “Force X” column to activate the input box, and enter 0.25 in the input box. Click **Apply** and then **OK**.

Before executing the file, go to menu **File -> Save As...** and save the file as example2.slb. Once this is completed, go to **Computations -> Run Analysis** to launch the analysis.




Figure 6.6 Defining edge nodes (BOTTOM edge nodes highlighted)

### 6.3.3 Output Results Review

When the analysis is completed, go to menu **Computations -> View Output File**. The deflection at node 1, the center deflection for the fixed square plate, is 0.0335379. Figure 6.7 shows the contour plot for the slab deflection. To view this, go to **Results -> Contour Plot**, in the Contour Plot Options check "Show Contour Plot" and under "Contour Variable" select "Disp X" and then click **Apply**. This result corresponds exactly to the computer generated numerical result for a 4x4 network as reported in *Finite Elements for Structural Analysis*, which is within 0.4% of the classical solution, 0.033397 in.




Figure 6.7 Contour plot of displacement in X for slab in Example 2

## 6.4 Example 3: Square slab on soil - distributed stiffness method

### 6.4.1 Problem Description

This example is included to model a square concrete slab resting on soil using 8-node isotropic plate elements. The slab is 24 ft x 24 ft and 10 in. thick. Young's modulus is taken as 3,000,000 psi and Poisson's modulus is 0.2. The subgrade modulus of the soil is assumed to be 200 psi per inch of deflection. A concentrated load of 10 kips is applied at the center of the slab.

### 6.4.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and Quadratic 8 Noded" for the Element Type. Enter the "Length" and "Width" as 288, and the "Number of Divisions" as 4, as shown in Figure 6.8. Click **OK** to draw the slab on the screen.




Figure 6.8 New Project from Template dialog screen for Example 3

Go to **Input Data** → **Title** and enter a name for the current project; this one is *Example 3*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default “Element Number/Set” value as ALL, select *Isotropic* under “Material Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to those given in the problem statement and then click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.

To set the soil stiffness, go to menu **Input Data** → **Distributed Stiffness**. Add a row using the **Add Row** button. Under the “Element Number” heading, enter ALL in the edit box, so the soil stiffness is distributed evenly beneath all of the slab elements. Next, check the box under the “D. Tr. K X” column and enter 200 in the associated edit box. Click **Apply** and then the **OK** button.

Next, go to menu **Input Data** → **Nodal Loads**. Add a row and enter the number of the middle node, 33. Check off the “Force X” box and enter 10000 for the load. Click **Apply** and then **OK**. Figure 6.9 shows the slab with the point load applied at the center and the distributed soil stiffness. To set this view go to **Options** → **Nodal Loads** and **Options** → **Distributed Stiffness**.

Before executing the file, go to **File** → **Save As...** and save the file as *example3.slb*. Once this is completed, go to **Computations** -**Run Analysis** to launch the analysis.

### 6.4.3 Output Results Review

When the analysis is completed, go to menu **Computations** → **View Output File**. The center deflection at node 33 is 0.00586678. This result is very close to the Westergaard solution for this problem, 0.0057 in., as reported in the text *Discontinuous Orthotropic Plates and Pavement Slabs*.

Now let us consider a different case using the same slab. This time, the 10 kip point load is applied along the edge of the slab. Save a copy of example3.slb as example3b.slb. Change the project title to Example 3b. Move the nodal load from node 33 to node 5, positioning the load at the middle of the lower edge of the slab. Save the file and run the analysis. The maximum deflection under the edge load is 0.0220390. The Westergaard closed form solution for this case is 0.019 in., as reported in the text *Discontinuous Orthotropic Plates and Pavement Slabs*.




Figure 6.9 Slab of Example 3 shown with soil stiffness and center point load

## 6.5 Example 4: Square slab on soil - Mindlin method

### 6.5.1 Problem Description

This example uses the same slab and loading condition as Example 3 to estimate the deformation of the slab based on Young's modulus of the soil which is entered externally. Instead of using the given soil subgrade modulus as soil springs, Young's modulus of soil is used to derive the soil stiffness beneath each nodal point.

### 6.5.2 Modeling Instruction

To solve this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog

box, choose “Rectangular – Equally Spaced” for the Shape and “Linear 4 Noded” the Element Type. Enter the “Length” and “Width” as 288, and the “Number of Divisions” as 8. Click **OK** to draw the slab on the screen.

Go to **Input Data -> Title** and enter a name for the current project; this one is *Example 4*. Click **OK** to save this as the project title. In this model a reduced integration 4 node element will be used, to apply this go to **Input Data -> Integration Points** and select “1 x 1 (reduced).” Return to the **Input Data** menu and proceed to **Material Properties**. Leave the default “Element Number/Set” value as **ALL**, select **Isotropic** under “Material Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to those given in the problem statement from example 3 and then click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.

The nodal edges must be restrained since there is no nodal stiffness applied for this case. Following the procedure described in Example 2, create a node set named **EDGE** and set the edge nodes to it. Go to **Input Data -> Node Set** then **Add Row** and enter the name **EDGE** into the edit box and click the **Define** button to launch the Node Set dialog. Using the **Add Row** button, enter 1 under “Node Number/Set,” 9 under “Final” and 1 under “Increment” to select the nodes to be defined in the bottom edge (nodes 1 through 9). Add a second row using the **Add Row** button, enter 73 under “Node Number/Set,” 81 under “Final” and 1 under “Increment” to select the nodes to be defined in the top edge (nodes 73 through 81). Add a third row, enter 10 under “Node Number/Set,” 64 under “Final” and 9 under “Increment” to select the nodes to be defined in the left edge (nodes 10, 19, 28, 37, 46, 55, 64). Add a fourth row, enter 18 under “Node Number/Set,” 72 under “Final” and 9 under “Increment” to select the nodes to be defined in the right edge (nodes 18, 27, 36, 45, 54, 63, 72). Click **Ok** to go back to the Node Set dialog box, and then click **Ok** to return to the main screen. Next, go to **Input Data -> Nodal Constraints** and restrain the **EDGE** set in the y and z directions. Click on **Add Row**, enter **EDGE** under “Node Number”, and check “Displac Y,” “Displac Z” and “Rotation X.” Click **Apply** and then **OK**.

To input the center load, go to **Input Data -> Nodal Loads**. Add a row and enter the number of the middle node, 41. Check off the “Force X” box and enter 10000 for the load. Click **Apply** and then **OK**. Figure 6.10 shows the slab with the point load applied at the center and the edge restraints. Next, go to **Input Data -> Soil Stiffness**. Select “Estimate Soil Stiffness using Mindlin Equation. For this example, a Young’s modulus of 17000, a Poisson’s ratio of 0.4, and an initial stiffness of 700 are assumed, click **OK** to return to the main screen. Go to **Input Data -> Time Stepping**, under “Max. Iterations/Step” enter 500, and under “Error Tolerance” enter 0.001, click **Ok** to return to the main screen.

Before executing the file, go to **File -> Save As...** and save the file as *example4.slb*. Once this is completed, go to **Computations -Run Analysis** to launch the analysis.




Figure 6.10 Slab of Example 4 shown with center load and edge restrains

### 6.5.3 Output Results Review

Execute the file and view the output data. To view the deformed shape, go to **Results -> Deformed Mesh** and check both options “Show Deformed Shape” and “Show Undeformed Model”. The graphic shown in Figure 6.11 was produced using a deformation factor of 500. The center deflection is reported to be 0.0061 inch. The Young’s modulus and initial stiffness values will need to be varied until the output deflection approaches that of the known value. A Young’s modulus of 17000 and an initial stiffness of 700 were used in this example.




Figure 6.11 Deformed shape of slab of Example 4 shown with center load and edge restrains

## 6.6 Example 5: Slab on soil to support four columns (no rotation restraint)

### 6.6.1 Problem Description

This problem models a square concrete slab resting on soil using 8-node isotropic plate elements. The slab is 10 ft. square and 2 ft. thick. Young's modulus is taken as 468,000 kip/ft<sup>2</sup> (ksf) and Poisson's modulus is 0.15. The subgrade modulus of the soil is assumed to be 100 kcf. A concentrated load of 125 kips is applied to four nodes around the plate center.

### 6.6.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and "Quadratic 8 Noded" for the Element Type. Enter the "Length" and "Width" as 10, and the "Number of Divisions" as 5. Click **OK** to draw the slab on the screen.

Go to menu **Input Data -> Title** and enter a name for the current project; this one is *Example 5*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default "Element Number/Set" value as *ALL*, select *Isotropic* under "Material

Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to those given in the problem statement and then click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.

To set the soil stiffness, go to menu **Input Data -> Distributed Stiffness**. Add a row using the **Add Row** button. Under the “Element Number” heading, enter **ALL** in the edit box, so the soil stiffness is distributed evenly beneath all of the slab elements. Next, check the box under the “D. Tr. K X” column and enter **100** in the associated edit box. Click **Apply** and then **OK** button.

Next, go to **Input Data -> Nodal Loads**. Because the load is applied in the center, and no node exists at that location, the load will be evenly divided among the four nodes of element 13 (39, 41, 56, and 58). Add four rows and enter a load of **125** for each node. Click **Apply** and then **OK**.

Before executing the file, go to **File -> Save As...** and save the file as *example5.slb*. Once this is completed, go to **Computations -> Run Analysis** to launch the analysis.

### 6.6.3 Output Results Review

When the analysis is completed, go to menu **Computations -> View Output File**. The deflection at node 39 is 0.0508956 ft. Moments  $M_y$  at corner node of element 13, are 50.344 kip\*ft/ft. These results are close to the solution reported in the text *Foundation Analysis and Design* for this slab. To view the how the slab deforms, go to **Results -> Deformed Mesh**, or to view the moment distribution, go to **Results -> Contour Plot** and select the desired moment.

Figure 6.12 shows the deformed slab with a deformation shape factor of 5 with the undeformed outline. Figure 6.13 shows the contour plot of the moment in the y direction. Figure 6.14 shows moment  $M_y$  of node 39 using nodal output option.




Figure 6.12 Deformed shape of slab of Example 5




Figure 6.13 Contour plot of moment distribution in the y direction of Example 5




Figure 6.14 Nodal output for moment My at node 39 in Example 5

## 6.7 Example 6: Slab on soil to support four concentrated forces (restrained nodal rotation)

### 6.7.1 Problem Description

This example uses the slab of Example 5, but this time assumes that nodes 39, 41, 56, and 58 are held against rotation in both y and z directions, simulating the presence of a fixed concrete column. Go to **Input Data -> Nodal Constraints** and add 4 rows. Under the "Node Number" column input 39 for row 1, 41 for row 2, 56 for row 3, and 58 for row 4, and check off "Rotation Y" and "Rotation Z" for each row. The deformation at node 39 drops to 0.0507750 ft., and the moment under the column becomes 44.19 kip\*ft/ft. The deformed shape and the contour plot of the moment in the y direction are shown in Figure 6.15 and Figure 6.16, respectively.




Figure 6.15 Apply node rotation constraints to simulate non-rotation at column foot in Example 6




Figure 6.16 Contour plot of moment distribution in the y direction of Example 6




Figure 6.17 Moment My at node 39 in Example 6

## 6.8 Example 7: Rectangular slab on soil subject to column loads

### 6.8.1 Problem Description

This example considers a rectangular concrete raft supporting four columns. The slab is 16m by 12 m, and is 0.8m thick. The concrete has a Young's modulus of 30 GPa (30000 MPa) and a Poisson's ratio of 0.2. The subgrade modulus of the soil is  $4 \text{ MN/m}^3$ . The columns provide a concentrated load of 5MN, 3MN, 6MN, and 8MN, respectively. The column locations are shown in Figure 6.18.

### 6.8.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and "Quadratic 8 Noded" for the Element Type. In the Y-direction enter the "Length" as 16 and "Number of divisions" as 16, In the Z-direction enter the "Width" as 12 and "Number of divisions" as 12. Click **OK** to draw the slab on the screen.

Go to **Input Data -> Title** and enter a name for the current project; this one is *Example 7*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default "Element Number/Set" value as ALL, select *Isotropic* under "Material Type" and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the

parameters to those given in the problem statement and then click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.

To set the soil stiffness, go to **Input Data -> Distributed Stiffness**. Add a row using the **Add Row** button. Under the Element Number heading, enter **ALL** in the edit box, so the soil stiffness is distributed evenly beneath all of the slab elements. Next, check the box under the “D. Tr. K X” column and enter 4 in the associated edit box. Click **Apply** and then the **OK** button.

Next, go to **Input Data -> Nodal Loads**. The columns are located at nodes 109, 129, 409, and 429. At node 109, enter a load of 5MN in the x direction; at node 129, a load of 3 MN; at node 409 a load of 8MN; and at node 429 a load of 6MN.

Before executing the file, go to **File -> Save As...** and save the file as *example7.slb*. Once this is completed, go to **Computations -> Run Analysis** to launch the analysis.




Figure 6.18 Location of columns on raft of Example 7

### 6.8.3 Output Results Review

When the analysis is completed, go to **Computations -> View Output File**. To view how the slab deforms, go to **Results -> Deformed Mesh**. Figure 6.19 shows the deformed slab with a deformation shape factor of 10 together with the undeformed outline. To view the moment, go to **Results -> Contour Plot** and select the desired moment axis. The maximum moment in the y direction is 1767.2 m-kN at the

8 MN column. The maximum moment in the x direction also occurs at the 8 MN column and is 1778.1 m-kN. Figure 6.20 shows the moment distribution of the raft along the y axis.

For viewing the section-cut plot, the user should click Section Cut item under Input Data menu and then select the cutting lines by default or by the user-specified. To view the deflection along the cutting line, go to **Results** → **Section Cut Plot** and select the desired cutting line and deflection as shown in Figure 6.21 for required display.




Figure 6.19 Deformed shape of slab with column loads of Example 7




Figure 6.20 Moment distribution of the slab in the y direction of Example 7




Figure 6.21 Deflection of the slab along the cutting line of Example 7

## 6.9 Example 8: Rectangular raft on soil to support columns and walls

### 6.9.1 Problem Description

This example considers a rectangular concrete raft supporting 10 columns and three wall sections. The slab is 16m by 8 m and is 0.8m thick. The concrete has a Young's modulus of 30000 MPa and a Poisson's ratio of 0.2. The subgrade modulus of the soil is  $30 \text{ MN/m}^3$ . The location of the walls and columns and the mesh size are shown in Figure 6.22.




Figure 6.22 Location of walls and columns in Example 8

### 6.9.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and "Quadratic 8 Noded" for the Element Type. In the Y-direction enter the "Length" as 16 and "Number of divisions" as 10, In the Z-direction enter the "Width" as 8 and "Number of divisions" as 8. Click **OK** to draw the slab on the screen.

To set the soil stiffness, go to **Input Data -> Distributed Stiffness**. Add a row using the **Add Row** button. Under the Element Number heading, enter **ALL** in the edit box, so the soil stiffness is distributed evenly beneath all of the slab elements. Next, check the box under the "D. Tr. K X" column and enter 30 in the associated edit box. Click **Apply** and then the **OK** button.

Next, go to **Input Data -> Nodal Loads**. The columns are located at nodes 1, 11, 21, 163, 169, 175, 257, 267, 271, 277, 107, 103. And the loads are 1.1, 1.22, 1.09, 0.29, 0.15, 0.83, 1.11, 1.05, 0.5, 1.34, 0.31, 0.44 (MN), respectively. The U-shape wall load is entered as follows. Go to **Input Data -> Edge Sets**. Create a new edge set named **WALL** (Click **Add Row** and enter **WALL** under the “Set” column). Then select **Define** and add six rows as shown in Figure 6.23. Once all the values are entered, click **Apply** and **OK** to return to the Edge Set dialog box, then click **OK** to return to the main screen. To assign the load to the wall, go to **Input Data -> Edge Loads**. Set the Edge column to **WALL**, under “DOF” enter 1 and place the 0.600 MN load in the Load Node 1, 2 and 3 columns, click **Apply** and **OK** to return to the main screen.

Before executing the file, go to **File -> Save As...** and save the file as *example8.slb*. Once this is completed, go to **Computations -> Run Analysis** to launch the analysis.




Figure 6.23 Location of edge set for U-shape wall in Example 8

### 6.9.3 Output Results Review

When the analysis is completed, go to **Computations -> View Output File**. To view how the slab deforms, go to **Results -> Deformed Mesh**. The deformed shape of the slab is shown in Figure 6.24. Moment distributions in the y and z directions are shown in Figure 6.25 and Figure 6.26. Note the locations of positive and negative bending






Figure 6.24 Deformation of slab in Example 8

Figure 6.25 Contour of bending moment  $M_z$

Figure 6.26 Contour of bending moment  $M_y$ 

## 6.10 Example 9: Wind turbine foundation supported by drilled shafts

### 6.10.1 Problem Description

A foundation design utilizing drilled shafts, hereafter referred to as a *drilled shaft foundation*, for a wind turbine generator would conceptually consist of a circular or square array of drilled shafts connected to a reinforced concrete cap (Figure 6.27). The wind turbine tower would then be attached to the cap with the use of post-tensioned anchor bolts anchored to an embedment plate within the cap, or an embedded portion of the wind turbine tower, commonly referred to as an Embedded Stub or Foundation Mounting Part (FMP) as shown in Figure 6.28. Drilled shafts would extend to a sufficient depth to resist design loads from overturning, torsion, and horizontal shear, as well as gravity loads from the wind turbine and associated components.

The unique requirements of structural design on a pile cap for a wind-turbine foundation include: (1) integrating the drilled shafts and the pier cap together so that the pile cap may reliably distribute the loads to each drilled shaft; and (2) integrating the base cap and the embedded mounting plate of the wind turbine tower to substantially reduce or eliminate the risk of pullout failure of the embedded mounting plate. The punching-shear failure near the heavily loaded shaft as well as the surface reinforcement for delivering the required bending capacity of the pile cap should also be evaluated in the pile-cap design.




Figure 6.27 Conceptual sketch of drilled-shaft foundation supporting a wind turbine

The diameter of the concrete pile cap is 6.835 m and the thickness of the pile cap is 1.5 m. The loads on the pile cap include (1) vertical load of 1108 kN, horizontal load of 550 kN, and bending moment of 21373.4 kN-m. The embedded mounting plate hosts a total of 96 anchor bolts which are arranged in two circular rings (Figure 6.28). The diameter of the outer ring is 1.959 m and the diameter of the inner ring is 1.839 m.




Figure 6.28 Dimension of pile cap and the embedded mounting plate with two rings of anchor bolts

### 6.10.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select “Circular or Rectangular Conventional” and click **Next**. In the Template dialog box, choose “Circular” for the Shape and “Linear 4 Noded” for the Element Type. Enter the diameter as 6.835 m, and the “Number of Divisions” as 64, as shown in Figure 6.29. Click **OK** to draw the slab on the screen.

Go to Input **Data** → **Title** and enter a name for the current project; this one is *Example 9*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default “Element Number/Set” value as **ALL**, select *Isotropic* under “Material Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box

modify the parameters to as Young's modulus of  $21,000,000 \text{ kN/m}^2$ , Poisson's ratio of  $0.3$ , and the thickness of  $1.5 \text{ m}$ . Click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen.




Figure 6.29 New Project from Template dialog screen for Example 9

It can be assumed that the pile cap is restrained completely (not allowing any translations) at the top of drilled shafts. The drilled shafts are assigned as node sets P1, P2, P3, P4, P5, P6, P7, and P8 based on the location.

To define the nodal sets (P1, P2, P3, P4, P5, P6, P7, and P8) to be used later for Nodal Constraints, click **Node Set** under Input Data Menu, and bring a dialog box as shown in Figure 6.30. Add 8 new rows and assign the names P1, P2, P3, P4, P5, P6, P7, and P8. Click the **Define** button under "Action" for each set name. As shown in Figure 6.31 to Figure 6.34, the nodal points which are covered by the contact area were entered with some convenient arrays. Those nodal points can be easily identified on the mesh plot by the Zone tool (Figure 6.35).

### Element Set

Set	Action
1 ALL	Define

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

1

### Node Set

Set	Action
1 ALL	Define
2 P1	Define
3 P2	Define
4 P3	Define
5 P4	Define
6 P5	Define
7 P6	Define
8 P7	Define
9 P8	Define

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

9

Figure 6.30 Node Set screen for Example 9

### Node Set - P1

Node Number/Set	Final	Increment
1 2543	2546	1
2 2607	2612	1
3 2671	2677	1
4 2736	2742	1
5 2800	2807	1
6 2865	2872	1
7 2930	2937	1
8 2995	3001	1
9 3060	3065	1
10 3125	3129	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

10

### Node Set - P2

Node Number/Set	Final	Increment
1 3465	3470	1
2 3529	3536	1
3 3593	3601	1
4 3657	3666	1
5 3722	3731	1
6 3787	3795	1
7 3852	3859	1
8 3917	3922	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

8

Figure 6.31 Definition of Node Sets P1 and P2 for Example 9

### Node Set - P3

Node Number/Set	Final	Increment
1 3486	3491	1
2 3550	3557	1
3 3615	3623	1
4 3680	3689	1
5 3745	3754	1
6 3811	3819	1
7 3877	3884	1
8 3944	3949	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

8

### Node Set - P4

Node Number/Set	Final	Increment
1 2590	2593	1
2 2654	2659	1
3 2719	2725	1
4 2784	2790	1
5 2849	2856	1
6 2914	2921	1
7 2979	2986	1
8 3045	3051	1
9 3111	3116	1
10 3177	3181	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

10

Figure 6.32 Definition of Node Sets P3 and P4 for Example 9

Node Set - P5

	Node Number/Set	Final	Increment
1	1680	1683	1
2	1614	1619	1
3	1549	1555	1
4	1484	1490	1
5	1419	1426	1
6	1354	1361	1
7	1289	1296	1
8	1225	1231	1
9	1161	1166	1
10	1097	1101	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

Node Set - P6

	Node Number/Set	Final	Increment
1	756	761	1
2	690	697	1
3	625	633	1
4	560	569	1
5	495	504	1
6	431	439	1
7	367	374	1
8	304	309	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

Figure 6.33 Definition of Node Sets P5 and P6 for Example 9

Node Set - P7

	Node Number/Set	Final	Increment
1	735	740	1
2	669	676	1
3	603	611	1
4	537	546	1
5	472	481	1
6	407	415	1
7	342	349	1
8	277	282	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

Node Set - P8

	Node Number/Set	Final	Increment
1	1633	1636	1
2	1567	1572	1
3	1501	1507	1
4	1436	1442	1
5	1370	1377	1
6	1305	1312	1
7	1240	1247	1
8	1175	1181	1
9	1110	1115	1
10	1045	1049	1

OK

Close

Apply

Sort

Add Row

Insert Row

Delete Row

Number of Rows

Figure 6.34 Definition of Node Sets P7 and P8 for Example 9




Figure 6.35 Node numbers on the screen for Example 9

To set the nodal constraints, go to **Input Data → Nodal Constraints**. Add one row for each drilled shaft location using the **Add Row** button. Under the Nodal Number heading, enter (P1, P2, P3, P4, P5, P6, P7, and P8) in the edit box, so the each represent the nodal points within the contact area of drilled shaft. Next, check the box under “Displac. X”, “Displac. Y”, and “Displac. Z” columns and enter 0 in the associated edit box (Figure 6.36). Click **Apply** and then the **OK** button.

Specified Nodal Displacements

Node Number		Displac. X	Displac. Y	Displac. Z	Rotation X	Rotation Y	Rotation Z
1	P1	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
2	P2	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
3	P3	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
4	P4	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
5	P5	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
6	P6	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
7	P7	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0
8	P8	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input checked="" type="checkbox"/> 0	<input type="checkbox"/> 0	<input type="checkbox"/> 0

OK  
Close  
Apply  
Sort  
Add Row  
Insert Row  
Delete Row  
Number of Rows  
8




Figure 6.36 Nodal constraints dialog screen for Example 9

Next, go to **Input Data → Equivalent Concentrated Loads**. The user can specify two circular rings for hosting 48 anchors at each ring and enter the diameters of each ring. The user also needs to specify the loads ( $F_x = 1108$  kN, and  $M_y = 21373.4$  kN) applied on the pile cap through the anchor bolts. Note that for this example the horizontal load was not applied since only actions out of plane were analyzed.

The program will calculate the location of each anchor bolt arranged in a circular pattern and the concentrated loads on each anchor bolt based on the anchor-bolt location and loading data as shown in Figure 6.37.

Equivalent Concentrated Loads

Loading

Fx 1108

Fy 0

Fz 0

Mx 0

My 0

Mz 21373.4

Ring 1 Data

Radius (ri) 1.839

Points (ni) 48

Angle (fi) 0

Ring 2 Data

Radius (re) 1.959

Points (ne) 48

Angle (fe) 0

Point of Application

X 0

Y 0

Z 0

Number of Rings

☐ One Ring

☒ Two Rings

☒ Show Values

Equivalent Loads

R...	N	X	Y	Z	Fx	Fy	Fz
Int 1	0.000...	1.839...	0.000...	-215...	0.000...	0.000...	0.000...
Int 2	0.000...	1.823...	0.240...	-213...	0.000...	0.000...	0.000...
Int 3	0.000...	1.776...	0.475...	-207...	0.000...	0.000...	0.000...
Int 4	0.000...	1.699...	0.703...	-198...	0.000...	0.000...	0.000...
Int 5	0.000...	1.592...	0.919...	-184...	0.000...	0.000...	0.000...
Int 6	0.000...	1.458...	1.119...	-168...	0.000...	0.000...	0.000...
Int 7	0.000...	1.300...	1.300...	-148...	0.000...	0.000...	0.000...
Int 8	0.000...	1.119...	1.458...	-126...	0.000...	0.000...	0.000...
Int 9	0.000...	0.919...	1.592...	-101...	0.000...	0.000...	0.000...
Int 10	0.000...	0.703...	1.699...	-75.2...	0.000...	0.000...	0.000...
Int 11	0.000...	0.475...	1.776...	-47.1...	0.000...	0.000...	0.000...
Int 12	0.000...	0.240...	1.823...	-18.0...	0.000...	0.000...	0.000...
Int 13	0.000...	0.000...	1.839...	11.54...	0.000...	0.000...	0.000...
Int 14	0.000...	-0.24...	1.823...	41.15...	0.000...	0.000...	0.000...
Int 15	0.000...	-0.47...	1.776...	70.25...	0.000...	0.000...	0.000...
Int 16	0.000...	-0.70...	1.699...	98.35...	0.000...	0.000...	0.000...
Int 17	0.000...	-0.91...	1.592...	124.9...	0.000...	0.000...	0.000...
Int 18	0.000...	-1.11...	1.458...	149.6...	0.000...	0.000...	0.000...

Visible Variables

☒ X

☒ Y

☒ Z

☒ Fx

☒ Fy

☒ Fz

OK Cancel Apply

Figure 6.37 Equivalent concentrated loads screen for Example 9

Before executing the file, go to **File** → **Save As...** and save the file as *example9.slb*. Once this is completed, go to **Computations** → **Run Analysis** to launch the analysis.

### 6.10.3 Output Results Review

When the analysis is completed, go to **Computations** → **View Output File**. The maximum vertical displacement is approximately 0.113 mm under compression and 0.097 mm under tension as shown in Figure 6.38. The contour of bending moment along the Y-axis is shown in Figure 6.39. The contour of shear along the XY-planes is shown in Figure 6.40.

For viewing the section-cut plot, the user should click Section Cut item under **Input Data** menu and then select the cutting lines by default or by the user-specified. To view the deflection along the cutting line, go to **Results** → **Section Cut Plot** and select the desired cutting line and deflection as shown in Figure 6.41 for required display.




Figure 6.38 Contour of deflection of Example 9




Figure 6.39 Contour of bending moment (My) of Example 9




Figure 6.40 Contour of shear on XY plane of Example 9




Figure 6.41 Bending moment (Mz) along a cutting line of Example 9

## 6.11 Example 10: Square slab on soil - Vlasov method

### 6.11.1 Problem Description

This example considers a square concrete slab resting on the soil. A concentrated force  $P = 56 \text{ kip}$  is applied at the center of the slab (Figure 6.42). The slab is 33 ft by 33 ft, and is 0.851 ft thick. The Young's modulus and the Poisson's ratio of the slab and soil are listed in Table 6-1. Assume the compressible thickness of the soil is 30 ft. Bottom boundary of the soil is assumed to be fixed in x,y,z directions.




Figure 6.42 Configuration of slab resting on soil of example 10

Table 6-1: Parameters of slab and soil in example 10

	Young's modulus E(ksf)	Poisson's ratio $\nu$	Thickness (ft)
slab	432000	0.15	0.851
soil	190	0.3	30

### 6.11.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the Slab Type dialog box select "Circular or Rectangular Conventional" and click **Next**. In the Template dialog box, choose "Rectangular – Equally Spaced" for the Shape and "Quadratic 8 Noded" for the Element Type. Enter 33 for both "Length" and "Width", and the "Number of Divisions" as 24. Here a fine mesh is desired because coarse mesh can't capture the peak forces near the concentrated load. Click **OK** to draw the slab on the screen.

Go to **Input Data - Title** and enter a name for the current project; this one is *Example 10*. Click **OK** to save this as the project title. Next, return to the **Input Data** menu and proceed to **Material Properties**. Leave the default "Element Number/Set" value as ALL, select *Isotropic* under "Material

Type” and click **Define** to open the Material Properties dialog box. In the Material Properties dialog box modify the parameters to as Young’s modulus of 432000000 psf (432000 ksf), Poisson’s ratio of 0.15, and the thickness of 0.851 m. Click **OK** to save the changes and close the dialog box. In the Material Data dialog box click **OK** to return to the main screen. To set the soil stiffness, go to **Input Data → Soil Stiffness**. Select the second option “Estimate Soil Stiffness using Vlasov Approach”. Input soil properties as shown in Figure 6.43. Keep the initial Gamma as 1.0. This default value works well for most cases. Click **OK** to return to the main screen.

Soil Stiffness

☐ Do not consider Soil Stiffness  
☒ Estimate Soil Stiffness using Vlasov Approach  
☐ Estimate Soil Stiffness using Mindlin Equation

Young Modulus at Top: 190000  
 Young Modulus at Bottom: 190000  
 Poisson's Ratio: 0.3  
 Soil Depth: 30  
 Initial Gamma: 1

OK Cancel

**Figure 6.43 Input soil properties in Vlasov approach**

Next, go to **Input Data → Nodal Loads**. The concentrated load is applied at the middle node (913). Click **Add Row** to add one new row, input 913 as the node number. Then check the option for Force X and input 56000 lbs (56 kip) as shown in Figure 6.44. Display of node number can be controlled by menu **Options → Node Numbers**.




Figure 6.44 Define concentrated load at slab center

Before executing the file, go to **File** → **Save As...** and save the file as example10.slb. Once this is completed, go to **Computations** → **Run Analysis** to launch the analysis.

### 6.11.3 Output Results Review

When the analysis is completed, go to **Computations** → **View Output File**. All deformation and internal forces are plotted into this file. Since the number of nodes in this example is large, it is not convenient to look for the output for one specific node. Go to **Results** → **Node Results**, then input node number 913 which is loaded. Check the deflection at this node is 0.01174 ft (Figure 6.45).




Figure 6.45 View node output for one specific node

Go to **Results** → **Section Cut Plot**, select “My” as the field variables. The distribution of moment “My” along the center line of the plate is plotted as shown in Figure 6.46. Change field variable to “Qxy” to plot the shear force along the same cut line as in Figure 6.47. Since a fine mesh is defined, the peak moment and shear force can be observed in these cut line plots.




Figure 6.46 Distribution of moment  $M_y$  along cut line 1 in example 10




Figure 6.47 Distribution of shear force  $Q_{xy}$  along cut line 1 in example 10

In the Vlasov approach, parameters  $\gamma$ ,  $k$  and  $2t$  are iterated until convergence of displacements is reached. The initial value of  $\gamma$  is set to 1 and the final  $\gamma$  increases to 1.81 as shown in Figure 6.48.

```

step    1   tcur   =   1.0000   dt =   1.0000

gamma =   1.000000, k =   0.8684E+04, 2t =   0.6456E+06

iter =   1   err1 = 0.1000E+01 d = 0.1999E+00 u = 0.1999E+00 rhs = 0.5600E+05
        err2 = 0.1000E+01 r = 0.2104E-01 ru= 0.2104E-01 rrhs= 0.0000E+00

gamma =   1.730552, k =   0.9564E+04, 2t =   0.5278E+06

iter =   2   err1 = 0.2800E-01 d = 0.5605E-02 u = 0.2002E+00 rhs = 0.4982E+03
        err2 = 0.4621E-01 r = 0.1018E-02 ru= 0.2204E-01 rrhs= 0.2091E+03

gamma =   1.800223, k =   0.9700E+04, 2t =   0.5165E+06

iter =   3   err1 = 0.4607E-02 d = 0.9196E-03 u = 0.1996E+00 rhs = 0.4885E+02
        err2 = 0.3094E-02 r = 0.6839E-04 ru= 0.2210E-01 rrhs= 0.1998E+02

gamma =   1.809304, k =   0.9719E+04, 2t =   0.5151E+06

iter =   4   err1 = 0.6331E-03 d = 0.1263E-03 u = 0.1995E+00 rhs = 0.6346E+01
        err2 = 0.3817E-03 r = 0.8439E-05 ru= 0.2211E-01 rrhs= 0.2586E+01

gamma =   1.810514, k =   0.9721E+04, 2t =   0.5149E+06

iter =   5   err1 = 0.8493E-04 d = 0.1694E-04 u = 0.1995E+00 rhs = 0.8452E+00
        err2 = 0.5049E-04 r = 0.1116E-05 ru= 0.2211E-01 rrhs= 0.3442E+00

```

Figure 6.48 Output of  $\gamma$ ,  $k$  and  $2t$  in example 10

The concentrated load of 56 k is applied at Node 913, which is approximately at the center of the slab. The shear force at the cutting line clearly indicates the change of shear force from negative to positive before and after Node 913 with the concentrate load as shown in Figure 6.47. The total change of shear force should yield the theoretical value of 56 k. However, the accuracy of numerical solution will depend mostly on the element sizes used near the concentrated load as indicated in Figure 6.49. When the element sizes are finer enough, the change of shear force gets closer to the theoretical value. The result from finer meshes is also in agreement with those computed based a three-dimensional model using ABAQUS from Dassault Systems.




Figure 6.49 Influence of mesh size to shear stress in example 10

## 6.12 Example 11: Circular wind turbine foundation – Vlasov method

### 6.12.1 Problem Description

This example considers a wind turbine foundation with circular shape (Figure 6.50). The parameters of soil are listed in Table 6-2. The depth of compressible soil is 30 ft. Dimensions of the concrete foundation are also listed in Table 6-2. Applied loads include vertical thrust force  $P = 696 \text{ kip}$ ,  $V = 81.6 \text{ kip}$ , and  $M = 25250 \text{ kip} \cdot \text{ft}$ . The loads are applied in  $xy$  plane in *GeoMat*. Units used in this example are *kip*, *ft*.




Figure 6.50 WTB foundation resting on soil of example 11


Table 6-2: Parameters of slab and soil in example 11

	Young's modulus $E(\text{ksf})$	Poisson's ratio $\nu$	Thickness (ft)	R1 (ft)	R2 (ft)	R3 (ft)	D1 (ft)	D2 (ft)	D3 (ft)
foundation	5.8e5	0.15		9	13.5	29	1	6.33	4
soil	1320	0.2	30						

### 6.12.2 Modeling Instruction

To compute this problem using *GeoMat*, use the **New from template** option in the **File** menu. In the foundation type selection dialog, select “Circular wind turbine foundation.” In the following template, input foundation dimensions and loads as shown in Figure 6.51. Keep the default division of 40. Keep the default “Quadratic 8-noded” element type and “2x2” integration rule. Click **OK** to generate the mesh.

Template of Circular Wind Turbine Foundation



**Plane Dimension**

R1 = 9  
 R2 = 13.5  
 R3 = 29  
 Angle(deg) = 0

**Section Dimension**

D1 = 1  
 D2 = 6.33  
 D3 = 4

**Load**

P = 696  
 V = 81.6  
 M = 25250

**Finite Element Option**

☐ Linear 4 noded  
☒ Quadratic 8 noded  
☐ Quadratic 9 noded  
 Division of  $2 \cdot \pi \cdot R3$  = 40  
 Typical FE Size = 2.28

**Integration Rule**

☐ 1x1  
☒ 2X2  
☐ 3X3

OK Cancel

Figure 6.51 Template for circular wind turbine foundation in example 11

Now define material parameters for the concrete foundation. Click menu **Input Data** → **Material Properties**. The foundation is divided into four sets based on different thicknesses. Click the name under “Element Number/Set” will highlight selected element set in cyan color (Figure 6.52).

Click button **Define** to change Young’s modulus  $E$  and Poisson’s ratio to  $5.8 \times 10^5$  and  $0.15$  respectively for each element set. Click **OK** to exit from the material property window.

The next step is to define soil parameters. Soil in the Vlasov approach is assumed to have one layer. Click menu **Input Data** → **Soil Stiffness** and select the second option “Estimate Soil Stiffness using Vlasov Approach.” Change Young’s both modulus at top and bottom to be 1320 as shown in Figure 6.54. Change Poisson ratio to  $0.2$ . Click **OK** to exit.

Click menu **Input Data** → **Nodal Loads** to check equivalent nodal loads calculated by *GeoMat* (Figure 6.55). Nodal loads are concentrated point forces in green color. Click **OK** to exit.




Figure 6.52 main window for material definition in example 11





Figure 6.52 main window for material definition in example 11



Material Properties

Element Number/Set: set\_1

Young Modulus: 5.8e5


Poisson's Ratio: 0.15

Slab Thickness: 11.33

OK

Cancel

Figure 6.53 Define Young's modulus and Poisson ratio for each slab sets in example 11



Soil Stiffness

☐ Do not consider Soil Stiffness

☒ Estimate Soil Stiffness using Vlasov Approach

☐ Estimate Soil Stiffness using Mindlin Equation

Young Modulus at Top: 1320

Young Modulus at Bottom: 1320

Poisson's Ratio: 0.2


Soil Depth: 30

Initial Gamma: 1

OK

Cancel

Figure 6.54 Define soil property using Vlasov approach in example 11



Nodal Loads

Node Number	Force X	Force Y	Force Z	Moment X	Moment Y	Moment Z
1	5.79404	0.679301	0	0	0	0
2	54.2654	0.679301	0	0	0	0
3	53.6686	0.679301	0	0	0	0
4	51.893	0.679301	0	0	0	0
5	48.9823	0.679301	0	0	0	0
6	45.0082	0.679301	0	0	0	0
7	40.0685	0.679301	0	0	0	0
8	34.2848	0.679301	0	0	0	0
9	27.7996	0.679301	0	0	0	0
10	20.7725	0.679301	0	0	0	0

OK

Close

Apply

Sort



Add Row


Insert Row

Delete Row

Number of Rows: 80

Figure 6.55 Check equivalent nodal loads in example 11

Click icon  on the toolbar to reset view to y-z plane. Click menu **Input Data->Nodal Constraints** to define displacement boundary to remove rigid body motion. Click **Add Row** to add one new line. Click icon  to activate *pick and select by mouse*. Pick the rightmost node (node 682) and check “Displac. Y” and “Displac. Z.” Keep displacement boundaries to be 0. Similarly add other two rows to define fixed point at node 686 and 678. Constrained nodes are displayed in Figure 6.56. Click **OK** to exit.



**Figure 6.56 Apply nodal constraints to remove rigid body motion in example 111**

Before executing the file, go to **File → Save As...** and save the file as example11.slb. Once this is completed, go to **Computations → Run Analysis** to launch the analysis.

When analysis is done, open message file to review iterations of  $\gamma$ ,  $k$  and  $2t$ . Click menu **Results->Section Cut Plot** to plot deflection along the first cut line as shown in Figure 6.57. The maximum is 0.0106 ft (0.127in).




Figure 6.57 Deflection along cut line 1 in example 11

## **CHAPTER 7.      References**

- Bowles, J.E., "Foundation Analysis and Design", McGraw-Hill Book Co., New York, 1982.
- Hudson, W. R. and Matlock, H. "Discontinuous Orthotropic Plates and Pavement Slabs", Center for highway research, university of Texas, Austin, 1966.
- Vallabhan C.V.G. and Das Y.C., "*A Parametric Study of Beams on Elastic Foundations*". J. of Engng. Mech. Div., **114**, 12, 2072–2082 (1988).
- Vlasov, V. Z. and U. N. Leontiev, Beams, Plates, and Shells on Elastic Foundation.
- Israel Program for Scientific Translations, Jerusalem, Israel 1966. (translated from Russian).
- Weaver, William Jr and Johnston, Paul R. "Finite Elements for Structural Analysis", Prentice-Hall, Inc. Engelwood Cliffs, New Jersey, 1984.
- Winkler, E., "Dielehre von der Elastizitat und Festigkeit", Prague, 1867.

## **License Agreement & Disclaimer**

## **PROGRAM LICENSE AGREEMENT & DISCLAIMER**

**IMPORTANT NOTICE:** The software you are about to install or previously have installed from Ensoft Incorporated (“ENSOF”) is licensed only on the condition that you agree to the terms and conditions set forth below. Please read the terms of this License Agreement & Disclaimer (“LICENSE”) carefully.

If you agree to be bound by the terms of this LICENSE, please check mark the box labeled “YES – I Accept the terms of this License Agreement!” during software installation so it can be installed on your computer.

If you do not agree to the terms of this LICENSE, please check mark the box labeled “NO – I DO NOT Accept the terms of this License Agreement!” which will terminate the software installation.

If the software is already installed and licensed, you have already agreed to the terms and conditions of this license, or someone has done so on your behalf.

This LICENSE is a legal agreement between you (“USER”) – either an individual or a single entity– and ENSOF for the ENSOF software product that you are about to install or previously have installed (“PRODUCT”). The PRODUCT collectively includes computer software and associated media, printed materials, hardware key (dongle), and electronic documentation. The PRODUCT also includes any updates and supplements to the original PRODUCT that may have been produced by ENSOF. By installing, copying, downloading, accessing or otherwise using the PRODUCT, the USER agrees to be bound by the terms of this LICENSE. If you (the USER) do not agree to the terms of this LICENSE, do not install or use the PRODUCT.

## **SOFTWARE LICENSE & DISCLAIMER**

The PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The PRODUCT is licensed, not sold.

### **1. GRANT OF LICENSE**

This LICENSE grants you the following rights:

#### **1.1 INSTALLATION AND USE**

##### **1.1.1 Single-User Licenses**

This software is licensed only to the USER (company or individual) whose name is registered with ENSOF and for one specific physical site (“SITE”) registered with ENSOF. You may install and use the PRODUCT on any number of computers at the licensed SITE. However, the PRODUCT is fully operational only in the SITE computer that carries the appropriate PRODUCT’s hardware key (“KEY”) that is used as software protection device.

##### **1.1.2 Network Licenses**

This software is licensed only to the USER (company or individual) whose name is registered with ENSOF and for the specific physical site(s) (“SITE(S)”) and IP range registered with ENSOF. Each network seat that is purchased is provided with access for SITE(S) clients located within up to 2 subnets with unique third octets (“CLIENT SUBNETS”). The minimum two-seat network license can be associated to a maximum of 4 CLIENT SUBNETS (within up to 4 unique third octets). Purchase of additional network seats can extend the allowable range of CLIENT SUBNETS.

The USER may install and use the PRODUCT on any computer in the licensed SITE(S) that is within the allowable CLIENT SUBNETS registered with ENSOF. Any one computer in the network can be designated as license server for the PRODUCT by carrying the appropriate PRODUCT’s hardware key (“KEY”) that is used as software protection device.

This Network License strictly prohibits the PRODUCT to be used in or from computers located in office locations that are different than the licensed SITE(S) or outside the registered CLIENT SUBNETS. Users in physical office locations other than the registered SITE(S) with ENSOF are required to purchase additional licenses of the PRODUCT, even if the COMPANY is the same and/or if the additional offices are located in the same city.

## 2. OTHER RIGHTS AND LIMITATIONS

### 2.1 EDUCATIONAL VERSION

If the PRODUCT was licensed with educational discounts, the use of the PRODUCT is strictly limited to academic or research activities of educators and/or students. Any other usage voids all the rights under this LICENSE. If in doubt, please contact ENSOFT to determine if you have a PRODUCT version that was licensed for educational purposes.

### 2.2 LIMITATIONS ON REVERSE ENGINEERING, DECOMPILE, AND DISASSEMBLY

You may not reverse engineer, decompile, or disassemble the PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

### 2.3 RENTAL

You may not rent, lease or lend the PRODUCT to third parties.

### 2.4 TRADEMARKS

This LICENSE does not grant you any rights in connection with any trademarks or service marks of ENSOFT.

### 2.5 SUPPORT SERVICES

ENSOFT shall provide you with limited support and maintenance services (“SUPPORT”) related to the PRODUCT during the initial year after purchase and for any additional SUPPORT term that the COMPANY elects to purchase for PRODUCT after the initial warranty period expires.

Use of SUPPORT is limited to the ENSOFT policies and programs described in the PRODUCT’s User’s Manual, in documentation on the ENSOFT web site, and/or in other materials provided by ENSOFT.

Any supplemental software code that may be provided to you as part of the SUPPORT or that is downloaded from the ENSOFT web site shall be considered part of the PRODUCT and subject to the terms and conditions of this LICENSE. With respect to technical information you provide to ENSOFT as part of the SUPPORT, ENSOFT may use such information for its business purposes, including for product support, development or advertisements. However, ENSOFT will not utilize such technical information in a form that personally identifies the USER.

### 2.6 SOFTWARE TRANSFER

The initial user of the PRODUCT may make a permanent transfer of this LICENSE and PRODUCT and only directly to an end user. This transfer must include all of the PRODUCT (including all component parts, the media and printed materials, any upgrades, this LICENSE, and the PRODUCT’s appropriate hardware KEY). Such transfer may not be by way of consignment or any other indirect transfer. The transferee of such one-time transfer must agree to comply with the terms of this LICENSE, including the obligation not to further transfer this LICENSE and PRODUCT.

### 2.7 TERMINATION

Without prejudice to any other rights, ENSOFT may terminate this LICENSE immediately if you fail to comply with the terms and conditions of this LICENSE. In such event, you must destroy all copies of the PRODUCT and all of its component parts and provide evidence of such destruction in writing to ENSOFT within 3 business days.

### 2.8 INDEMNIFICATION

Within and during the terms of this LICENSE, ENSOFT warrants that the use of the initially provided PRODUCT does not infringe any patent, copyright, or trademark in the United States, and ENSOFT shall indemnify and hold USER harmless against any and all losses, damages and expenses, (including attorney’s fees) which USER may sustain or incur as a result of a breach of this warranty.

### 2.9 CONFIDENTIAL INFORMATION

ENSOFT and the USER may have access to certain proprietary information and materials of the other that are confidential and of substantial value to the respective party, which value would be impaired if such information were disclosed to third parties ("CONFIDENTIAL INFORMATION"). ENSOFT and the USER agree that neither shall disclose any CONFIDENTIAL INFORMATION to any third party and shall take every reasonable precaution to protect CONFIDENTIAL INFORMATION.

The provisions of this section shall not apply to any information which (i) is or becomes available to the public other than by breach of the LICENSE agreement by the receiving party, (ii) is rightfully received by receiving party from a third party without confidential limitations, (iii) is independently developed by receiving party's employees without access to CONFIDENTIAL INFORMATION, or (iv) is known to the receiving party without any restriction on its use or disclosure prior to first receipt of it from the disclosing party.

### **3. COPYRIGHT**

All title and intellectual property rights in and to the PRODUCT (including but not limited to any images, photographs, animations, video, audio, music, and text that may be incorporated into the PRODUCT), the accompanying printed materials, and any copies of the PRODUCT are owned by ENSOFT. All title and intellectual property rights in and to the content which may be accessed through use of the PRODUCT is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This LICENSE grants you no rights to use such content. All rights not expressly granted are reserved by ENSOFT. This PRODUCT is protected by the United States Copyright Law and International Copyright Treaty.

### **4. SOFTWARE DISCLAIMER**

Although the PRODUCT has been used with apparent success in many analyses, new information is developed continuously and new or updated PRODUCT releases may be written from time to time. All users are requested to inform ENSOFT immediately if any errors are found in the PRODUCT. As modifications, updates, or new versions are produced, the latest codes are posted on ENSOFT's web site and made available to all visitors for free downloading.

No warranty, expressed or implied, is offered as to the accuracy of results from ENSOFT's PRODUCT. The PRODUCT should not be used for design unless caution is exercised in interpreting the results and independent calculations are available to verify the general correctness of the results. Users are assumed to be knowledgeable of the information in the printed documentation that is distributed with the digital media. Users are assumed to recognize that the input parameters, eg., soil properties, increment length, tolerance on solution convergence, and many others, can have a significant effect on the solution and must be chosen carefully. Users should have a thorough understanding of the relevant theoretical criteria (appropriate references are suggested in the software documentation).

### **5. GOVERNING LAW**

This LICENSE is governed by the laws of the State of Texas and laws and treaties of the United States of America.

### **6. CONTACT INFORMATION**

Should you have any questions concerning this LICENSE or if you desire to contact ENSOFT for any reason, please use the following:

Ensoft Incorporated  
3003 West Howard Lane  
Austin, Texas 78728  
United States of America

### **NO OTHER WARRANTIES**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, ENSOFT DISCLAIMS ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND TITLE, WITH REGARD TO THE PRODUCT, AND THE PROVISION OF SUPPORT SERVICES. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHERS, WHICH VARY FROM STATE/JURISDICTION TO STATE/JURISDICTION.

**LIMITATION OF LIABILITY**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL ENSOFT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE PRODUCT OR THE FAILURE TO PROVIDE SUPPORT, EVEN IF ENSOFT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, ENSOFT'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU FOR THE PRODUCT OR U.S.\$1.00.